



DIGITRACE NGC-CMA

CONTENTS

1. Product Overview.....	4
1.1. DigiTrace NGC-CMA configuration and monitoring software.....	4
1.2. DigiTrace NGC-CMA Programming Guide	5
1.3. DigiTrace NGC-20 HANDHELD Software – License Agreement.....	5
1.4. User Responsibilities.....	7
1.5. Safety Warnings.....	7
2. How to Run the DigiTrace NGC-CMA Program	8
3. Initial Setup of the unit	8
4. Using the DigiTrace NGC-CMA in Standard Mode.....	8
4.1. Initial Setup of the unit in Standard Mode	8
5. Changing the Language of the user interface screens.....	9
6. Temperature units	9
7. Establishing a Bluetooth connection between the DigiTrace NGC-CMA and	10
DigiTrace DigiTrace NGC-20 control units.....	10
8. Configuring DigiTrace NGC-20 control units	11
8.1. Changing the DigiTrace NGC-20 controller settings	12
8.2. Changing the Temperature set point of a DigiTrace NGC-20 control unit	12
8.3. Changing the Switch control mode	13
8.4. Changing DigiTrace NGC-20 device tag name	15
8.5. Changing the NGC-20 console units.	15
8.6. Load Shed / Temperature Source Communications time out	16
8.7. Setting the Auto Cycle Interval.	16
8.8. Alarm Output Mode	17
8.9. Setting up Load Shedding	17
9. Changing DigiTrace NGC-20 Temperature Settings and Temperature Alarms.....	19
9.1. Changing NGC-20 Temperature Sensor Type (Sensor 1).	19
9.2. Setting High and Low Temperature Alarm Set Points (Sensor 1)	19
9.3. High and Low Alarm Filter (Sensor 1).....	20
9.4. Defining which temperature input is used for control.....	21
9.5. Assigning Temperature sensor Tag name	22
9.6. Setting up Fail Safe mode and High Limit Cut-Out Set point	22
9.7. Setting the High Limit Cut-Out Set point	23
9.8. Configuring the DigiTrace NGC-20 Temperature Sources.....	23
9.9. Temperature Sensor Configuration.....	24
10. Electrical Settings	25
11. SIL 2 Safety Temperature Limiter Settings.....	28
11.1. Resetting the Safety Temperature Limiter.....	30
11.2. Trip Limiter - Test function for SIL approved Safety Temperature limiter	31
12. Maintenance data.....	32
12.1. Force User Configuration Defaults.....	34
13. Alarm Masks.....	35
14. DigiTrace NGC-20 Monitoring screens	36
15. DigiTrace NGC-20 Alarm screens.	39

16. Firmware / Settings (communication settings)	40
16.1. Upgrading firmware of the DigiTrace NGC-20 control unit	40
16.2. Changing the serial interface settings of the DigiTrace NGC-20 control unit	42
16.3. DigiTrace NGC-20 Display Test.	42
16.4. DigiTrace NGC-20 Mode settings	42
17. Using the DigiTrace NGC-CMA in Mixed Mode	43
17.1. Initial Setup of the unit in Mixed Mode	43
18. Changing main settings of the user interface screens	44
18.1. Languages	44
18.2. Temperature units	44
19. Establishing connection between the DigiTrace NGC-CMA and DigiTrace NGC-20 control units	45
20. Configuring DigiTrace NGC-20 control units	46
20.1. Changing the NGC-20 controller settings	47
20.2. Changing the Temperature set point of a DigiTrace NGC-20 control unit	47
20.3. Changing the Switch control mode	48
20.4. Changing DigiTrace NGC-20 device tag name	50
20.5. Load Shedding	51
21. DigiTrace NGC-20 Temperature settings and temperature alarms	53
21.1. Changing NGC-20 Temperature sensor type (Sensor 1)	53
21.2. Fail Safe mode and High Limit Cut-Out Set point	54
22. Electrical Settings	55
23. SIL 2 Safety Temperature Limiter Settings	56
23.1. Safety Limiter Setpoint	57
23.2. Resetting Safety Temperature Limiter	59
23.3. Trip Limiter	59
24. Maintenance data	60
25. DigiTrace NGC-20 Monitoring screens.	62
26. DigiTrace NGC-20 Alarm screens	63
27. Upgrading firmware of the DigiTrace NGC-20 control unit	64
Appendices and Indexes	66

1. PRODUCT OVERVIEW


This document describes the use and the capabilities of the DigiTrace NGC-CMA handheld device and software. For more information about the correct use and handling of the device we refer to DigiTrace NGC-CMA Getting Started (INSTALL-131) manual.

1.1. DigiTrace NGC-CMA configuration and monitoring software.

The DigiTrace NGC-CMA software is developed for Windows Mobile 5. The software enables DigiTrace NGC-20 control units to be configured and monitored via a Wireless Bluetooth interface. The exact use of this software is described in this manual.

Note: For hazardous area (Zone 1, 21 and Zone 2, 22 use the DigiTrace NGC-CMA-EX only)

The DigiTrace NGC-20 can be configured in either Standard mode or Mixed mode. The Mixed mode meets situations where DigiTrace NGC-20 is communicating with a DigiTrace NGC-UIT, otherwise the DigiTrace NGC-20 will be configured in Standard mode. In both circumstances a different set of parameters is available for configuration.



Configuration and Monitoring

The NGC-CMA can be used to configure the DigiTrace NGC-20. Besides its function as programming interface the DigiTrace NGC-20-CMA can also be used to monitor DigiTrace NGC-20 units while they are in operation. When used in monitoring mode all process variables used by the NGC-20 control units can be visualised on the screen of the DigiTrace NGC-CMA

Installation

Please refer to the User Manual (INSTALL-131) for guidelines about unpacking and basic use of the DigiTrace NGC-CMA devices.

Communications

DigiTrace NG-CMA devices support various types of communications interfaces. Refer to the User Manual (INSTALL-131) or product datasheet for complete details about all communication options.

1.2. DigiTrace NGC-CMA Programming Guide

Vital Information

This manual is a guide for the setup and operation of the DigiTrace NGC-20-CMA handheld programming devices.

Important: All information, including illustrations, is believed to be reliable. Users, however, should independently evaluate the suitability of each product for their particular application.

Pentair Thermal Management makes no warranties as to the accuracy or completeness of the information, and disclaims any liability regarding its use.

Pentair Thermal Management' only obligations are those in the Pentair Thermal Management Standard Terms and Conditions of Sale for this product, and in no case will Pentair Thermal Management or its distributors be liable for any incidental, indirect, or consequential damages arising from the sale, resale, use, or misuse of the product. Specifications are subject to change without notice. In addition, Pentair Thermal Management reserves the right to make changes—without notification to Buyer—to processing or materials that do not affect compliance with any applicable specification.

1.3. DigiTrace NGC-20 HANDHELD Software – License Agreement

This agreement is a legal agreement between you, "the end user", and Pentair Thermal Management, LLC ("Pentair Thermal Management"). BY INSTALLING OR OTHERWISE ACCESSING THIS PROGRAM, YOU ARE AGREEING TO BECOME BOUND BY THE TERMS OF THIS AGREEMENT. IF YOU DO NOT AGREE TO THE TERMS OF THIS AGREEMENT, DO NOT INSTALL OR ACCESS THIS PROGRAM. IF INSTALLING OR OTHERWISE ACCESSING THIS PROGRAM BY OPENING A SEALED DISK PACKAGE, PROMPTLY RETURN THE UNOPENED DISK PACKAGE AND THE OTHER ITEMS (INCLUDING WRITTEN MATERIALS OR OTHER CONTAINERS) TO THE PLACE WHERE YOU OBTAINED THEM.

GRANT OF LICENSE

The DigiTrace NGC-20 handheld Software (the "Software") is licensed, not sold, to you for use only under the terms of this Agreement, and Pentair Thermal Management reserves any rights not expressly granted to you. Subject to the terms and conditions of this Agreement, Pentair Thermal Management grants to you a non-exclusive, nontransferable, limited license (without the right to sublicense others) to use the one copy, including written materials if any, of the Software on a single computer at the location (company and address) to which Pentair Thermal Management issued this copy of the DigiTrace NGC-20 handheld Software. The Software is owned by Pentair Thermal Management LLC and is protected by United States copyright laws and international treaty provisions. All copies made by you are subject to the terms and conditions of this Agreement. The structure, organization and code of the Software are valuable trade secrets and confidential information of Pentair Thermal Management. You agree not to modify, alter, merge, adapt, duplicate, distribute, translate, decompile, disassemble, reverse engineer, create derivative works, copy for use on any other computer or at any other location, or otherwise make this software available to any person or entity outside this location. The Software is licensed only to you. In no event may you transfer, sell, sublicense, rent, assign or transfer rights, lease, or otherwise dispose of the Software on a temporary or permanent basis without the prior written consent of Pentair Thermal Management. You agree to use reasonable efforts to protect against the unauthorized copying and use of the Software by others. You agree not to remove, disable or circumvent any proprietary notices or labels contained on or within the Software.

OTHER RESTRICTIONS

You may not sublicense, rent or lease the DigiTrace NGC-20 handheld Software to anyone.

You agree to notify Pentair Thermal Management promptly if "bugs" or seemingly incorrect or anomalous behaviour is discovered when using the Software.

You agree that the DigiTrace NGC-20 handheld Software, including written materials (if any) and all copies in whole or in part, will be destroyed or returned to Pentair Thermal Management at the written request of the Pentair Thermal Management Product Manager.

By installing or otherwise accessing the DigiTrace NGC-20 handheld Software you acknowledge that you have read and understood Pentair Thermal Management' Disclaimer of Warranty and Limitation of Liability, set forth below.

You agree to use reasonable efforts to protect against the unauthorized copying and use the DigiTrace NGC-20 handheld Software by others.

DISCLAIMER OF WARRANTY

THE DIGITRACE NGC-20 HANDHELD SOFTWARE AND ACCOMPANYING WRITTEN MATERIALS ARE PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND. THE ENTIRE RISK AS TO THE RESULTS AND PERFORMANCE OF THE DIGITRACE NGC-20 HANDHELD SOFTWARE IS ASSUMED BY YOU. PENTAIR THERMAL MANAGEMENT DOES NOT WARRANT THAT THE FUNCTIONS CONTAINED IN THE SOFTWARE WILL MEET YOUR REQUIREMENTS OR THAT THE OPERATION OF THE SOFTWARE WILL BE UNINTERRUPTED OR ERROR-FREE, OR THAT PROGRAM DEFECTS WILL BE CORRECTED.

LIMITED WARRANTY – MEDIA

THE MEDIUM ON WHICH THE PROGRAM IS ENCODED IS WARRANTED TO BE FREE FROM DEFECTS IN MATERIAL AND WORKMANSHIP UNDER NORMAL USE FOR A PERIOD OF SIXTY (60) DAYS FROM THE DATE OF DELIVERY TO YOU AS EVIDENCED BY A COPY OF YOUR RECEIPT. ALTHOUGH PENTAIR THERMAL MANAGEMENT BELIEVES THE MEDIA AND THE PROGRAM TO BE FREE OF VIRUSES, THE MEDIUM AND THE PROGRAM ARE NOT WARRANTED TO BE VIRUS FREE. PENTAIR THERMAL MANAGEMENT LIABILITY AND YOUR EXCLUSIVE REMEDY IF THE MEDIUM IS DEFECTIVE OR INCLUDES ANY VIRUS SHALL BE PROMPT REPLACEMENT OF THE MEDIUM WITH A NEW DIGI-TRACE NGC-20 HANDHELD SOFTWARE PRE-ENCODED DISC.

EXCLUSION OF ALL OTHER WARRANTIES

EXCEPT AS EXPRESSLY PROVIDED ABOVE, PENTAIR THERMAL MANAGEMENT DISCLAIMS ALL WARRANTIES, EITHER EXPRESS, IMPLIED OR STATUTORY, INCLUDING BUT NOT LIMITED TO ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, EVEN IF PENTAIR THERMAL MANAGEMENT HAS BEEN ADVISED OF SUCH PURPOSE. THIS AGREEMENT GIVES YOU SPECIFIC LEGAL RIGHTS. SOME STATES OR COUNTRIES DO NOT ALLOW THE EXCLUSION OF WARRANTIES SO THE ABOVE EXCLUSION MAY NOT APPLY TO YOU.

LIMITATION OF LIABILITY

THE ENTIRE RISK AS TO THE RESULTS AND PERFORMANCE OF THE SOFTWARE IS ASSUMED BY YOU. IN NO EVENT SHALL PENTAIR THERMAL MANAGEMENT, ITS AFFILIATES, DIRECTORS, OFFICERS, SHAREHOLDERS, EMPLOYEES OR OTHER REPRESENTATIVES BE LIABLE FOR DAMAGES OF ANY KIND, INCLUDING WITHOUT LIMITATION, ANY LOSS, DAMAGE, OR DELAY, OR FOR ANY LOST PROFITS, LOSS OF USE, INTERRUPTION OF BUSINESS, OR FOR ANY COMPENSATORY, SPECIAL, INCIDENTAL, CONSEQUENTIAL, INDIRECT DAMAGES (HOWEVER ARISING, INCLUDING NEGLIGENCE) OF ANY KIND ARISING OUT OF OR IN CONNECTION WITH THE USE OF, OR THE INABILITY TO USE, THE SOFTWARE OR THIS AGREEMENT (EVEN IF PENTAIR THERMAL MANAGEMENT HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES). FURTHER, IN NO EVENT SHALL PENTAIR THERMAL MANAGEMENT, ITS AFFILIATES, DIRECTORS, OFFICERS, SHAREHOLDERS, EMPLOYEES OR OTHER REPRESENTATIVES BE LIABLE TO YOU IN AN AMOUNT GREATER THAN THE AMOUNT ACTUALLY PAID BY YOU, IF ANY, FOR THE SOFTWARE.

YOU FURTHER AGREE THAT REGARDLESS OF ANY STATUTE OR LAW TO THE CONTRARY, ANY CLAIM OR CAUSE OF ACTION ARISING OUT OF OR RELATED TO USE OF THE SOFTWARE OR THE TERMS AND CONDITIONS MUST BE FILED WITHIN ONE (1) YEAR AFTER SUCH CLAIM OR CAUSE OF ACTION AROSE OR BE FOREVER BARRED.

INDEMNITY

To the extent allowed under federal and state law, you agree to indemnify and hold Pentair Thermal Management, its parents, subsidiaries, affiliates, officers, employees, sponsors and partners harmless from any claim, loss, cost, expense, demand, or damage, including reasonable attorneys' fees, arising directly or indirectly out of (a) your use of, or inability to use, the Software, (b) your activities in connection therewith, or (c) your breach of this Agreement or violation of the rights of any other party.

TERMINATION

The license granted herein will automatically terminate without notice from Pentair Thermal Management if you fail to comply with any term or condition of this Agreement. You agree, upon such termination, to remove the DigiTrace NGC-20 handheld Software from any memory and/or storage media or device, and to return the DigiTrace NGC-20 handheld Software, including all media and written materials, or destroy the same and certify such destruction to Pentair Thermal Management, along with any backup or other copies in your possession.

COMPLETE AGREEMENT – MODIFICATION IN WRITING

This Agreement constitutes the sole and complete understanding between the parties with respect to the DigiTrace NGC-20 handheld Software and its use, and may not be varied except by a writing signed by an officer of Pentair Thermal Management. You agree that you may not rely on any representations concerning the DigiTrace NGC-20 handheld Software to the extent they vary from this Agreement, and such representations, if any, will neither add to nor vary the terms of this Agreement.

CHOICE OF LAWS. This Agreement is governed by the laws of the State of California and the United States, including U.S. Copyright Laws.

EXPORT LAWS

The DigiTrace NGC-20 handheld Software may require a license from the U.S. Department of Commerce or other governmental agency before it may be exported. The term "export" includes many acts (such as transferring the DigiTrace NGC-20 handheld Software to a foreign citizen within the United States), in addition to sending or taking the DigiTrace NGC-20 handheld Software outside the United States. You agree to ascertain the necessary licensing procedures and obtain any required licenses before exporting the DigiTrace NGC-20 handheld Software. You also agree to indemnify Pentair Thermal Management and assume all financial responsibility for any losses it may suffer if you do not comply with this paragraph.

GOVERNMENT RESTRICTED RIGHTS

User acknowledges that the DigiTrace NGC-20 handheld Software has been developed at private expense and is provided with "Restricted Rights." Use, duplication or disclosure by the Government is subject to restrictions as set forth in subparagraph (b)(3) and paragraph (c) of the Rights in Technical Data clause at 48 C.F.R. 252.227-7013, or subparagraphs (c)(1) and (2) of the Commercial Computer Software – Restricted Rights clause at 48 C.F.R. 52.227-19, as applicable. This provision applies to the DigiTrace NGC-20 handheld Software acquired directly or indirectly by or on behalf of any government. The DigiTrace NGC-20 handheld Software is a commercial product, licensed on the open market at market prices, and was developed entirely at private expense and without the use of any government funds. Any use, modification, reproduction, release, performance, display, or disclosure of the DigiTrace NGC-20 handheld Software by any government shall be governed solely by the terms of this Agreement and shall be prohibited except to the extent expressly permitted by the terms of this Agreement, and no license to the DigiTrace NGC-20 handheld Software is granted to any government requiring different terms.

ASSIGNMENT

You may neither assign any right nor delegate any obligation under this Agreement and attempted assignment or delegation shall be void. Pentair Thermal Management may freely assign this agreement and its rights and obligations there under to any third party.

INVALID PROVISIONS

If any of the provisions of this Agreement are invalid under any applicable statute or rule of law, they are to that extent deemed omitted.

WAIVER

No failure or delay of Pentair Thermal Management in exercising or enforcing any right or provision of this Agreement shall constitute a waiver of such right or provision, or any other right or provision hereunder. Furthermore, any waiver by Pentair Thermal Management of any right or provision of this Agreement shall not be construed as, or constitute, a continuing waiver of such right or provision, or waiver of any other right or provision of this Agreement.

HEADINGS

The section titles in this Agreement are for convenience only.

SURVIVABILITY

You agree that the terms and conditions of this Agreement shall survive any termination of this Agreement and your rights to use the Software.

Should you have any questions concerning this Agreement, or if you want to contact Pentair Thermal Management for any reason, please write to:

HOUSTON

7433 Harwin Drive
Houston, TX 77036
Tel: +1.713.868.4800
Fax: +1.713.868.2333
pentairthermal.com

1.4. User Responsibilities

The performance, reliability and safety of your heat-tracing system depend on proper design, selection, and installation. The DigiTrace NGC-20-CMA will help you to configure and monitor a system that meets your requirements, but it is only a tool. It assumes that your input is accurate, that you are familiar with heat-tracing system design and configuration, and that you will ensure that all components of the heat-tracing system are installed, maintained and used as intended. The configuration of the DigiTrace NGC-20 handheld should be reviewed by a knowledgeable engineer to ensure it is appropriate for your application. Additional information relating to safety, design, and installation is contained in Design Guides, Installation Manuals, Data Sheets, and other literature available from Pentair Thermal Management. Be sure to consult these documents as needed.

1.5. Safety Warnings

There are important safety warnings which are shipped with Pentair Thermal Management products and that are also printed in DigiTrace NGC-30 Installation Manual (INSTALL-112) and NGC-20 installation manual (INSTALL-130). Be sure to read, understand and follow these safety warnings to reduce the risk of fire, shock, or personal injury. If you have any questions, contact your local representative or contact Pentair Thermal Management directly.

Warning, Error, and Alarm Messages

Under certain conditions, the DigiTrace NGC-20-CMA will alert the user with a warning an alarm or an error message. These are typically either because the program cannot find an acceptable answer based on user input, or because the user may need to take some additional action to ensure the design requirements are completely met. These warnings and error messages are detailed in chapter 9 of this manual.

For questions, please contact Pentair Thermal Management' Technical Support.

Technical Support

For technical support, contact your local representative, or contact Pentair Thermal Management directly:

HOUSTON

7433 Harwin Drive
Houston, TX 77036
Tel: +1.713.868.4800
Fax: +1.713.868.2333
pentairthermal.com

BELGIUM

Romeinse straat 14
3001 Leuven
Tel: +32.16.213.511
Fax: +32.16.213.603
pentairthermal.be

2. HOW TO RUN THE DIGITRACE NGC-CMA PROGRAM



3. INITIAL SETUP OF THE UNIT


After the program is started the start up screen will be visualised. The start up screen allows users to configure the unit to their personal needs and process requirements.

4. USING THE DIGITRACE NGC-CMA IN STANDARD MODE


When operated in the Standard Mode the maximum set of parameters are available for configuration and monitoring. The following chapters will describe in detail how the DigiTrace NGC-20 can be configured and be monitored via the NGC-CMA.


4.1. Initial Setup of the unit in Standard Mode

After the program is started the start up screen will be visualised. The start up screen allows users to configure the unit to their personal needs and process requirements.


DigiTrace Configuration Utility Main screen	
 <p>Figure 4 1: Startup screen</p>	<p>The Tab "Configure" initiates the Bluetooth device discovery process.</p> <p>The tab "Settings" allows setting the Language, Temperature units, and shows the software revision.</p> <p>The tab "Exit" closes the application.</p> <p>Begin the initial configuration by tapping on Settings on the start up screen. This will open the Setup screen as shown in</p>

5. CHANGING THE LANGUAGE OF THE USER INTERFACE SCREENS.


DigiTrace Configuration Utility Main screen	
 <p>Figure 5 1: Setup Screen</p>	<p>About: shows the software version of the DigiTrace Configuration Utility Software.</p> <p>Languages: Allows selecting a convenient language of the user interface software.</p> <p>Temperature Units: Sets the temperature units of the DigiTrace NGC-CMA. Supported are: Degrees Celsius and degrees Fahrenheit. The default value is degrees Celsius.</p> <p>Back: Brings you back to the previous screen (Figure 4.1)</p> <p>Tap on Languages to continue</p>

 <p>Figure 5 1: Setup Screen</p>	<p>Supported languages are:</p> <p>English (default)</p> <p>French (Français)</p> <p>German (Deutsch)</p> <p>After tapping on the desired language, you will be returned to the Startup screen ()</p> <p>Remark; selecting a different language will cause the unit to reboot. Allow enough time for the unit to completely reboot. When ready revert back to step 1 in order to restart the application. The application will now run in the selected language.</p>
---	---

6. TEMPERATURE UNITS

 <p>Figure 6 1: Temperature Units Screen</p>	<p>From the Setup Screen tap on Temperature Units to change the way in which temperatures will be displayed on the NGC-CMA screens. The factory default setting is °C.</p> <p>Tapping on the desired field will select the units of measure Celsius or Fahrenheit and will return you to the <i>Setup Screen</i> while the new units of measure will be selected.</p> <p>Tap on Back to return to the Startup Screen.</p>
--	--

7. ESTABLISHING A BLUETOOTH CONNECTION BETWEEN THE DIGITRACE NGC-CMA AND DIGITRACE NGC-20 CONTROL UNITS

DigiTrace Configuration Utility Main Screen	
 <p>Figure 7 1: Main Screen</p>	<p>From the Startup screen tap on Configure. The display will now show the Bluetooth discovery screen and the device discovery process will be started.</p>

Bluetooth Discovery Process

Bluetooth Discovery

Please wait,
Discovering devices...



Back

Continue

Figure 7 2: Bluetooth Discovery screen – Searching for devices

In background the device will scan for all DigiTrace NGC-20 controllers which are within range of the Bluetooth communications. Ensure that all DigiTrace NGC-20 units are powered up.

Bluetooth Discovery Process (building the device inventory list)

Bluetooth Discovery

Please select the device you
wish to connect to

NGC-20-1



Scan for Devices

Back

Continue

Figure 7 3: Bluetooth Discovery screen – one device found

When searching is complete all devices in range will be listed on the screen.

Example: For this example, the only device that is found is NGC-20-1. If more than one

DigiTrace NGC-20 control unit is in range all units will be listed on the screen as is shown on Figure 7-4.

Bluetooth Discovery Process (selecting device)

Bluetooth Discovery

Please select the device you
wish to connect to

NGC-20-1

NGC-20-2



Scan for Devices

Back

Continue


Figure 7 4: Bluetooth Discovery screen – finding 2 devices

Now select the device you want to connect to by tapping on the device name. When a device is selected the background color will be black (see NGC-20-1). Next tap on **Continue** to go on to the Main configuration screen.

If devices are not showing up repeat the device discovery process by simply tapping on **Scan for Devices once more**.


8. CONFIGURING DIGITRACE NGC-20 CONTROL UNITS

In order to configure the connected DigiTrace NGC-20 control unit tap on **continue**

DigiTrace NGC-20 Main Configuration Screen	
 <p>Figure 8 1: Main screen</p>	<p>The main screen supports different options as is shown on Figure 8 1.</p> <p>Tap Configure: to configure the selected unit.</p> <p>Tap Monitor to look at all process variables as currently active on this unit. All measured sensor temperatures, control temperature, load current, supply voltage, ground fault current and the status of the safety limiter.</p> <p>Tap View Alarms in order to get an overview of all active alarms and to reset alarms.</p> <p>Tap Firmware / Settings in order to install a new version of firmware in the selected controller.</p> <p>Tap Back to go back to the Bluetooth discovery screen as shown on Figure 7-4.</p>

8.1. Changing the DigiTrace NGC-20 controller settings

Tap on Configure in the NGC-20 Main screen. As a result of this the NGC-20 Configuration screen will be shown. The NGC-20 configuration screen supports different options:

DigiTrace NGC-20 Configuration Screen	
 <p>Figure 8 2: NGC-20 Configuration screen</p>	<p>Tap Controller Settings to alter; set points, control mode, dead band, the device tag and load shedding.</p> <p>Tap Temperature Settings to alter High and Low Temperature alarm values, the temperature alarm filter, fail safe mode and to enable and preset the high limit Cut-Out</p> <p>Tap Temp. Source Settings to define the temperature sources used by this DigiTrace NGC-20 unit.</p> <p>Tap Electrical Settings in order to set the high and low load current and voltage alarm values. The second screen offers the possibility to load the relay cycles time counter and to adjust the ground fault alarm warning and trip level.</p> <p>Tap Temperature Limiter; use this entry in order to control the Safety temperature limiter set point, trip and reset the Safety temperature limiter after it has tripped.</p> <p>Tap Maintenance to get information about the minimum and maximum values ever seen by the unit. Of the following variables the minimum and maximum are stored; Control temperature, AC Voltage, Ground fault current, Load current, Relay cycle count, Heater hours in use Time and the Safety Limiter temperatures.</p> <p>Tap Alarm Masks to specify for which variables an alarm will be generated</p> <p>Tab Back brings you to the Configuration screen</p>

8.2. Changing the Temperature set point of a DigiTrace NGC-20 control unit

Tap on Controller Settings. This will open a next screen showing the actual Controller settings. In order to change any of the values tap on the field holding the actual variable.


Controller Settings	
 <p>Controller Settings</p> <p>Temperature Setpoint: 35°C</p> <p>Switch Control Mode: On/Off</p> <p>Deadband: 1°C</p> <p>Settings 1 Settings 2 { ◀ ▶ }</p> <p>Back Apply</p>	<p>Tap on the field holding the actual value (35°C). A numeric key pad as shown in Figure 8 4 will pop up.</p>

Figure 8 3: Controller Settings – Settings 1 screen




Numeric Input Screen (Temperature Setpoint)	
 <p>Temp Setpoint</p> <p>10 C</p> <p>Min: -80 Max: 700</p> <p>7 8 9 Clear</p> <p>4 5 6 Cancel</p> <p>1 2 3 Enter</p> <p>0 . - +</p>	<p>Enter the desired temperature set point by tapping on the screen and press Enter to complete.</p> <p>- For this example, we will be using a Setpoint of 10°C. As soon as you tap the enter button you will be brought back to the Controller Settings screen.</p> <p>REMARK: The numeric screen is used at various places throughout this manual everywhere where numeric values are to be changed or entered.</p>


Figure 8 4: Temp Set point Numeric Screen


8.3. Changing the Switch control mode


When returned to the Controller Setting screen of Figure 8 3 on the input field under **Switch Control Mode**.

Switch Control Mode	
 <p>Figure 8 5: Control Mode settings Screen</p>	<p>The switch control mode defines in which manner the output switch will be operated in order to maintain the desired temperature. Tap on the desired Switch Control Mode. The NGC-20 supports a number of different control modes as shown on Figure 8 5</p> <p>The different control modes supported are:</p> <ul style="list-style-type: none">▶ On / Off▶ Prop. Ambient Contactor▶ PASC contactor▶ Force On▶ Force OFF▶ Cancel <p>Note that depending on the selected control mode the input fields in the previous and next screens will vary.</p> <p>Cancel will bring you back to the Controller Settings screen (Figure 8 3).</p>

Controller Settings 1 (On/Off)	
 <p>Figure 8 6: Controller Settings 1</p>	<p>On/Off is a simple set point / on-off operation.</p> <p>Set in the Dead band Field the desired dead band.</p> <p>Note that the Dead band will be above set point.</p> <p>Example; a set point of 40°C and dead band of 5 will turn the heating off at 45°C and on at 39°C.</p>


Controller Settings 1 (Prop. Ambient Contactor)	
 <p>Figure 8 7: Controller Settings</p>	<p>Prop. Ambient Contactor: see PASC below.</p> <p>PASC Contactor takes advantage of the fact that the heat loss from a pipe is proportional to the temperature difference between the pipe and the ambient air. This is true regardless of heater type, insulation type, or pipe size. Once the heat tracing and insulation on a pipe has been designed to balance heat input with heat loss and maintain a particular temperature, the main variable in controlling the pipe temperature becomes the ambient air temperature. The DigiTrace NGC-20 has a control algorithm that uses the measured ambient temperature, desired maintain temperature, minimum ambient temperature assumption used during the design stage, and size of the smallest pipe diameter to calculate how long the heater should be on or off to maintain a near-constant pipe temperature.</p> <p>Proportional Band: is the delta between the desired temperature (set point) and the minimum expected ambient temperature.</p> <p>The Prop. Ambient Cycle Time defines the total time cycle (Sum of the ON + OFF cycle) in minutes. The cycle time can be adjusted between minimum 10 and Maximum 255 minutes. The ON/OFF ratio will be calculated based on the measured ambient temperature.</p>

 <p>Figure 8 8: Controller Settings</p>	<p>The Power Adjustment factor (min 10% to Max 200%) The Power adjustment factor can be used to influence or override the calculated ON /OFF ration values in excess of 100% will lead to more heat, values below 100% will reduce the temperature.</p> <p>Tap Apply to confirm your new settings</p>
--	---

Controller Settings 1 (Force ON / Force OFF)	
 <p>Figure 8 9: Controller Settings</p>	<p>Force On The relay output is permanently switched on (user override), turns on the power to the heater and leaves it on.</p> <p>Force OFF The relay output is permanently switched off (user override), turns off the power to the heater, and leaves it off.</p> <p>Note: Remember to monitor the pipe temperatures for Low / High temperature alarms when selecting Force ON or Force OFF control mode.</p> <p>Tap Apply after the desired control mode has been selected.</p>

8.4. Changing DigiTrace NGC-20 device tag name

Tap on **Settings 2** on the bottom of the controller settings screen (Figure 8-6 till Figure 8-9).

Controller Settings 2	
 <p>Figure 8 10: Controller Settings – Settings 2 screen</p>	<p>This screen allows you to change the NGC-20 device tag. Tags can be 39 characters in length and may contain all numeric characters. Enter the desired Tag for the NGC-20 device by tapping in the actual device tag or elsewhere in that field. (NGC-20-1)</p> <p>Console Units: field allows changing the way temperature units are shown on the DigiTrace NGC-20 control units' display. Temperature can be shown in degrees Fahrenheit or Celsius</p> <p>Load Shed / Temperature Source Communications Timeout</p>

NGC-20 Tag

NGC-20 Tag

Pipe #1

Cancel

OK



Figure 8 11: Temp Set point Numeric Screen

Enter the desired Tag by using the onscreen keyboard. Tap **OK** when finished.

- For this example, the new tag will be "Pipe #1".

8.5. Changing the NGC-20 console units.

Tap on the field Console units to change the readout of the DigiTrace NGC-20 Control units display.

Console Units

Console Units

Celsius

Fahrenheit

Cancel

Figure 8 12: NGC-20 Console Units screen

Tap on the desired console units.

8.6. Load Shed / Temperature Source Communications time out

Load shedding is a control mode that can be programmed and initiated only by an external communicating device, which overrides temperature control and forces the output of the controller OFF until the override is removed. When using an external device (DigiTrace Supervisor Software or a DCS), a load shedding command is continually broadcast over the communications network.

When power is applied, the controller delays energising its trace by 'x' number of seconds, where 'x' is equal to the last digit in its network address. If the load shed function is enabled, the controller will go into load shed mode before it turns its output on. It will then look for the broadcasted load shed command. If the controller receives the load shed command before it times out, it will remain in load shed mode, and the output will remain off as long as the module receives a regular broadcast of the command. If the controller does not receive the load shed command within the timeout period, it will energise its output and resume normal operation. The timing of this broadcast (and the timeout value) can vary between 30 seconds and 10 minutes. A total of 16 different load shedding zones can be defined.

Enter confirms the new settings and returns to Figure 8-10 Controller Settings – Settings 2 screen.

Controller Settings

NGC-20 Tag:
NGC-20-1

Console Units:
Celsius

Load Shed / Temperature
Source Communications
Timeout:
10 Min

Settings 1 Settings 2 ◀ ▶

Back Apply

Figure 8 10

8.7. Setting the Auto Cycle Interval.

Tap on Settings 3 on the bottom of the controller settings screen of Figure 8-6 till Figure 8-10

Controller Settings 3	
<p>Controller Settings</p> <p>Auto-Cycle Interval: 1 hrs</p> <p>Alarm Output Mode: Normal Operation</p> <p>Alarm Output Toggle Time: 60 sec</p> <p>Settings 2 Settings 3 ◀ ▶</p> <p>Back Apply</p>	<p>This screen allows you to change the NGC-20 device tag. Tags can be 39 characters in length and may contain all numeric characters. Enter the desired Tag for the NGC-20 device by tapping in the actual device tag or elsewhere in that field. (NGC-20-1)</p> <p>Console Units: field allows changing the way temperature units are shown on the DigiTrace NGC-20 control units' display. Temperature can be shown in degrees Fahrenheit or Celsius</p> <p>Load Shed / Temperature Source Communications Timeout</p>

Figure 8 13: Controller settings - Settings 3 screen

8.8. Alarm Output Mode

The Alarm Output Mode defines the way the alarm relay will act in case of alarms. The different options are: Normal Operation, Toggle, Flash or cancel.


Alarm Output Mode	
	<p>Normal operation: Selecting this will result in the alarm relay changing state in case of an alarm. (General alarm) This means the open contact will close and the closed contact of the SPDT alarm relay will open.</p> <p>Toggle: selecting toggle will cause the Alarm relay to change state each time a new alarm comes up.</p> <p>Flash: selecting to Flash the Alarm relay will alternatively open and close the Alarm relay. The interval itself can be user defined in the Alarm Output Toggle Time</p> <p>Cancel will take you back to the previous screen without any of the changes made.</p>

Figure 8 14: Alarm Output Mode

8.9. Setting up Load Shedding

A total of 16 different load shedding zones can be defined.


Load Shedding 1	
	<p>If a load shedding command is present, the controller will continue to hold the output OFF, until one of two conditions occurs:</p> <ol style="list-style-type: none">1. The zone definition flags of an external communicating device which initiated load shedding clears and the command to terminate load shedding mode is issued.2. Communications are interrupted between the controller and its communicating device, as in the case of a damaged communications wire. If communication ceases for a specified timeout value, the controller will return to normal operation. The value for this timeout is programmable within the controller (30 seconds to 600 seconds). <p>Note: The controller will return to normal operation if communications between the external communicating device and the controller are disrupted in any way. This will return temperature control to the HTC. Also, the HTC does not perform a periodic autocycle test while operating in load shed mode.</p>

Figure 8 15:Controller Settings, Load Shedding 1

Load Shedding 2

Controller Settings

- ☐ Zone 8 Shedding Enabled
- ☐ Zone 9 Shedding Enabled
- ☐ Zone 10 Shedding Enabled
- ☐ Zone 11 Shedding Enabled
- ☐ Zone 12 Shedding Enabled
- ☐ Zone 13 Shedding Enabled
- ☐ Zone 14 Shedding Enabled
- ☐ Zone 15 Shedding Enabled
- ☐ Zone 16 Shedding Enabled

Load Shedding 2 ◀ ▶

Back **Apply**

Figure 8 16: Controller Settings, Load Shedding 2

Three parameters must be set in the controller to configure it for load shedding operation:

1. The load shedding feature must be enabled.
2. The FAIL SAFE MODE parameter must be enabled or disabled depending on the application requirements. If FAIL SAFE MODE is enabled, then at least one LOW TS ALARM (of a TS used in the TS CONTROL MODE) must be enabled. If the alarm temperature exceeds the CONTROL SETPOINT temperature, fail-safe mode will be disabled.
3. The zone definition flags of an external communicating device that are to be associated with the load shedding action for the controller must be defined. The NGC40 controller will support up to 16 different zones.

These parameters can only be configured using an external communicating device connected to the bridge or DigiTrace UIT.


Notes:

- Fail-safe mode is always disabled if the SWITCHCONTROL MODE is set to either of the two proportional ambient control modes, or the TS CONTROL MODE = EXT INPUT, FAIL OFF/ON
- The HTC will turn on its output switch when the control temperature becomes less than the highest LOW TS ALARM temperature if the following conditions are met:
 - Fail-safe mode is enabled
 - Load shedding is active
 - The TS CONTROL MODE uses both TS 1 and TS 2
 - Both TS 1 and TS 2 have their LOW TS ALARMS enabled
- A FORCE ON override signal has higher priority than a load shedding signal. An INHIBIT signal has higher priority than fail safe mode.

Tapping the Back button brings you back to the NGC-20 configuration screen (Figure 8 2: NGC-20 Configuration screen)


9. CHANGING DIGITRACE NGC-20 TEMPERATURE SETTINGS AND TEMPERATURE ALARMS

On the DigiTrace NGC-20 Configuration screen (Figure 9 1) tap on Temperature Settings.




9.1. Changing NGC-20 Temperature Sensor Type (Sensor 1).

The first screen of the temperature settings screen enables configuration of the sensors. The DigiTrace NGC-20 control unit supports only one type of temperature control input (Pt 100 -3-wire)



9.2. Setting High and Low Temperature Alarm Set Points (Sensor 1)



9.3. High and Low Alarm Filter (Sensor 1)

High and Low Alarm Filter Sensor 1

Temperature Settings

Temperature Sensor 1 Type:

3 Wire 100 Ω Platinum

High Alarm Setpoint:

65°C

Low Alarm Setpoint:

-10°C

High Alarm Filter:

0 sec

Low Alarm Filter:

7 sec

Sensor 1

Sensor 2

Conti◀▶

Back

Apply

Figure 9 4: Temperature Settings: Sensor 1 screen

Alarm filters

can be seen as an alarm delay. This means that when the temperature drops below the Low Alarm Set point the DigiTrace NGC-20 Control unit will only trigger an alarm when the value entered in the Low Alarm Filter is timed out. This means that if immediate action of the alarm output is required, the Low Alarm Filter value should be set at 0 sec. Any other value will result in a delay. The operation of the High Alarm Filter is the same. Min 0 to Max 59940 seconds

Repeat Steps from

Temperature Settings

Temperature Sensor 1 Type:

3 Wire 100 Ω Platinum

High Alarm Setpoint:

65°C

Low Alarm Setpoint:

-10°C

High Alarm Filter:

0 sec

Low Alarm Filter:

7 sec

Sensor 1

Sensor 2

Conti◀▶

Back



Apply

Figure 9 2 for Sensor 2 in order to configure the second temperature input connected to the DigiTrace NGC-20 control unit. Hit Apply when done. The Back button will bring you back to the NGC-20 Configuration screen of Figure 8 2.

20

9.4. Defining which temperature input is used for control

The third screen of the Temperature Settings menu defines the Temperature Control Mode.

Temperature Settings	
	<p>Use the Temperature Control Screen to define which temperature input is chosen for control. Of all the temperature input options one input needs to be selected for control. Alternatively the control temperature can be based on the average or the lowest temperature of all temperature inputs currently connected and enabled.</p> <p>High Temperature Alarm Set point (range from min -80 to Max +700°C) Enter in this field the value at which - when surpassed - you want the NGC-20 control unit to generate a high temperature alarm. This high temperature condition will be monitored by the temperature sensor or group of temperature sensors selected for control.</p> <p>Low Temperature Alarm Set point (range from min -80 to Max +700°C) Enter in this field the value at which - when surpassed - you want the DigiTrace NGC-20 control unit to generate a low temperature alarm. This low temperature condition will be monitored by the temperature sensor or group of temperature sensors selected for control.</p> <p>High and Low Temperature Alarm Filter (Range from Min 0 to Max 59940 seconds) Alarm filters can be seen as an alarm delay. This means that when the temperature drops below the Low Alarm Set point the DigiTrace NGC-20 Control unit will only trigger an alarm when the value entered in the Low Alarm Filter is timed out. This means that if immediate action of the alarm output is required, that the Low Alarm Filter value should be set at 0 sec. Any other value will result in a delay. The operation of the High Alarm Filter is the same. Hit Apply when done</p>
	<p>Note that TS 1 and TS 2 are inputs directly connected to the input terminals of the DigiTrace NGC-20 unit, whereas the temperature inputs TS 3 to TS 8 are optional through the use of MONI-RMM2-E temperature multiplexing units and an NGC-30-UIT. Please refer to the installation instructions of these products for more details.</p> <p>Lowest: Setting the Temperature Control to Lowest means that the output of the DigiTrace NGC-20 will be controlled based on the lowest temperature measured by any of the temperature sensors connected to the DigiTrace NGC-20 either direct to the Temperature sensor inputs TS 1 or TS 2 or any other sensor connected via MONI-RMM2-E and DigiTrace NGC-UIT.</p> <p>Average: Setting the Temperature Control to Average means that the output of the DigiTrace NGC-20 will be controlled based on the average temperature measured by all the Temperature sensors connected to the DigiTrace NGC-20 either direct to the Temperature sensor inputs TS 1 and TS 2 and any other sensor connected via MONI-RMM2-E and DigiTrace NGC-UIT.</p>

9.5. Assigning Temperature sensor Tag name

The third screen of the Temperature settings enables an easy recognisable Tag name to be assigned to each individual Temperature sensor.

Sensor 1 Tag

Sensor 1 Tag

NGC20-RTD1-Demo 03

Cancel

OK

123 1 2 3 4 5 6 7 8 9 0 - =

Tab q w e r t y u i o p l j

CAP a s d f g h j k l ; ' ,

Shift z x c v b n m , . / +

Ctrl alt

Figure 9 7: Temperature Settings: Sensor Tag screen

Sensor Tags fields can contain a maximum of 39 characters and may contain numeric and alpha numeric values. Confirm the new sensor tag by tapping on the OK button. When appropriate also edit the Temperature Sensor 2 Tag name

9.6. Setting up Fail Safe mode and High Limit Cut-Out Set point

The Fail safe mode defines the output of the DigiTrace NGC-20 output switch in case of a sensor failure. Tap on the entry field behind Fail mode for more options

Sensor 1 Tag

Temperature Settings

Fail Mode: Fixed %

Fail Mode %: 50 %

High Limit Cut-Out: 700°C

Latch Temperature Alarms:
☐ No ☒ Yes

Latch High Temperature Cut-Out Alarm:
☒ No ☐ Yes

Control Tags Other

Back

Apply

Figure 9 8: Temperature Settings: Other screen

Temperature Fail Mode

Fail Off

Fail On

Last %

Fixed %

Cancel

Figure 9 9: Temperature Settings: Temperature Fail Mode screen

The different Fail modes supported by the DigiTrace NGC-20 are:

Fail Off: meaning that if the control sensor(s) of this DigiTrace NGC-20 unit should fail the output switch will open. Use this for all circuits where keeping the heating cables permanently powered could cause overheating.

Fail On: meaning that if the control sensor(s) of this DigiTrace NGC-20 unit should fail the output switch will be permanently close. This is the preferred option for freeze protection lines and most self regulating heating systems.

Last %: this Fail Mode is only applicable to the control mode PASC or Proportional Ambient sensing. The Fail Safe mode Last % will control the output in a similar manner as it was doing before the sensor(s) failed. This Alternate ON/OFF switching will be time based only - there will be no relation to temperature.

Fixed %: The Fail Mode Fixed % will alternate the control output ON and OFF at a certain interval.

Choose the desired fail safe mode from the list by tapping on that field

Cancel will bring you back to the previous screen as shown in Figure 9-8.

9.7. Setting the High Limit Cut-Out Set point

Tap in the field of the High Limit Cut-Out. This will open the numeric key pad. Enter the new High Limit Cut-Out set point and confirm the new set point by tapping Enter.


Temperature Settings	
 <p>The screenshot shows the 'Temperature Settings' screen. It includes fields for 'Fail Mode' (set to 'Fail Off'), 'Fail Mode %' (set to '50 %'), and 'High Limit Cut-Out' (set to '40°C'). There are radio buttons for 'Latch Temperature Alarms' (set to 'No') and 'Latch High Temperature Cut-Out Alarm' (set to 'No'). At the bottom, there are tabs for 'Control', 'Tags', and 'Other', and two buttons: 'Back' and 'Apply'.</p>	<p>The High Limit Cut-Out actually works as a temperature limiter which can be configured to operate as either a latching or non-latching type. When the Latching button is set to YES than each time an alarm has occurred the Alarm needs to be manually reset. When set to NO than the alarms will be self-healing and will disappear when the alarm condition is no longer present.</p> <p>Confirm your new settings by tapping the Apply button. After that tap on Back to return to Figure 9 1: NGC-20 Configuration screen</p>

Figure 9 10: Temperature Settings: Temperature Fail Mode screen

9.8. Configuring the DigiTrace NGC-20 Temperature Sources

DigiTrace NGC-20 units can be configured to read from various types of temperature sources / temperature sensors. Use the following screens to configure the DigiTrace NGC-20 control unit. Tap on Temp Source Settings (Figure 9 1: NGC-20 Configuration screen).


NGC-20 Configuration	
 <p>The screenshot shows the 'NGC-20 Configuration' screen. It features a vertical list of buttons: 'Controller Settings', 'Temperature Settings', 'Temp. Source Settings', 'Electrical Settings', 'Safety Limiter', 'Maintenance', 'Alarm Masks', and 'Back'.</p>	<p>This will open a new screen as is shown on Figure 9-12.</p>

Figure 9 11: NGC-20 Configuration screen


 <p>The screenshot shows the 'Temperature Sources' screen. It features a vertical list of buttons: 'Temperature Source 1', 'Temperature Source 2', 'Temperature Source 3', 'Temperature Source 4', 'Temperature Source 5', 'Temperature Source 6', 'Temperature Source 7', 'Temperature Source 8', and 'Back'.</p>	<p>Select the Temperature source you want to configure by tapping on the field.</p> <p>One DigiTrace NGC-20 Control unit can be configured with up to 8 Temperature Sources.</p> <p>2 of these sources are local (hardwired) to the NGC-20 unit, the remaining inputs can be configured through optional MONI-RMM2-E and NGC-UIT modules.</p>
---	---

Figure 9 12: Temperature Sources

Temperature Source Mode 1

Temperature Source Mode:
Local

Temperature Configuration:
Used For Control

☒ Temperature Input 1
☐ Temperature Input 2

Back Apply

Figure 9 13: Temperature Source mode 1

Temperature Source

Not Used

Local

Remote

Cancel

Figure 9 14: Temperature Source mode 1

Temperature Source Mode: in this first field the installation method of the temperature source needs to be specified. The different options are:

Not Used: means that this temperature sensor is not being used

Local: means that the temperature source is hard wired to the input terminals of the DigiTrace NGC-20 control unit. This can be either to the terminals labelled with TS 1 or the one labelled as TS 2.

Tapping on the field of your choice will bring you back to the previous screen (Figure 9 13).

Remote: this means that this particular temperature Source is imported through the use of optional MONI-RMM2 and NGC-UIT units. Refer to the operating manual of the DigiTrace NGC-30 for more details. Tapping on Remote will require that you enter the Gateway ModBus Address, Gateway Port Number and the ModBus address of the MONI-RMM2 device to which the temperature Source is physically connected. Refer to the operating manual of the DigiTrace NGC-30-UIT for more details. Confirm your settings by tapping on Apply.

Cancel will bring you back to the previous screen.

9.9. Temperature Sensor Configuration

The next screens allow you to configure the use of the temperature sensors.

Temperature Configuration

Temperature Configuration

Not Used

Used For Control

High Limit Cut-Out

High Limit And Control

Cancel

Figure 9 15: Temperature Configuration

The different options are:

Not Used: tap on this field in case the temperature sensor is not used.

Used for Control: tap on the field Used For Control if you want this temperature input to be used as primary input for control. (drives the control logic of the DigiTrace NGC-20)

High Limit Cut-Out: tap on this field if you want to configure this temperature source as an input for the high temperature cut out function of the DigiTrace NGC-20. The High Limit Cut-Out function prevents the heated surface from overheating. When the High Cut-Out Temperature Setpoint is reached the NGC-20 Output will be turned OFF regardless of whether or not the maintain temperature is reached. Use this function for instance to prevent the cable surface temperature exceeding a certain level.

High Limit And Control: this combines the function Used for Control and High Limit Cut-Out. This function only applies where multiple sensors are being used to control one circuit, for instance on by-passes. Confirm your settings by tapping on Apply.

Back will return to the screen Figure 9-12.

10. ELECTRICAL SETTINGS

To set up the electrical Settings in the Configuration menu, tap on Electrical Settings in Figure 10 1: NGC-20 Configuration screen.




Figure 10 1: NGC-20 Configuration screen

Electrical Settings (Alarm Set points 1)	
<div><p><i>Electrical Settings</i></p><p>High Load Current: 30.0 A</p><p>Low Load Current: 0.5 A</p><p>High Voltage: 254 V</p><p>Low Voltage: 90 V</p><p>Alarm Setpoints 1 Alarm ◀ ▶</p><p>Back Apply</p></div> <p>Figure 10 2: Electrical Settings / Alarm Setpoints 1 screen</p>	<p>The Electrical Settings Alarm Set points Screen 1 allows the following variables to be adjusted:</p> <p>High / Low Load Current (Range Min 0.3 – Max 30A) The Load Current alarm will generate an alarm each time the Load Current supplied to the heating cable exceeds the defined band. The load current is the same as the heater current.</p> <p>High and Low Voltage (Range Min 50 – Max 305 VAC) The voltage alarm will generate an alarm each time the power supply voltage supplying the NGC-20 control unit and the heating cables exceeds the defined band.</p>

Electrical Settings (Alarm Set points 1)

Electrical Settings

High GF Current:
10 mA

Ground Fault Trip Current:
20 mA

Contactor Cycle Count Limit:
2000000 Cycles

Heater On Time:
100000 hrs

Alarm Setpoints 2 Alarm ◀ ▶

Back Apply

Figure 10 3: Electrical Settings / Alarm Setpoints 2 screen

The Electrical Settings Alarm Set points Screen 2 allows the following variables to be adjusted:

High GF Current (Range Min 10 – Max 250 mA)

This field holds the value at which an early warning will be generated in the form of a High GF alarm. Typical value between 15 and 20 mA.

Ground Fault Trip Current (Range Min 10 – Max 250 mA)

The GF Trip Current field holds the value at which a ground fault signal will trip the output permanently OFF. Typically GF Trip is set at a slightly higher value than the **High GF Current** Set point. Typical value is between 20 and 30 mA

Ground Fault Trip (Enable / Disable) setting the Ground Fault Trip to Disabled, disables the Ground Fault Trip function. The High GF Alarm would still be generated when the leakage current exceeds the alarm value.

Contactor Cycle Count Limit (Range Min 0 – Max 2000000)

The Contactor Cycle Count counts the number of switch operations the Control output of the NGC-20 has made since the last reset. Each switch operation will subtract one (1) from the value entered in the counter. When the counter runs empty an alarm will be generated.

Heater On Time (Range Min 1 – Max 1000000 hrs) The Heater On Time Alarm is an hour counter which record the actual time the output is closed and the heating cables are used since the last reset.

Confirm your new settings by tapping on the Apply button. Click on Back to return to NGC-20 Configuration screen.

Electrical Settings

High Voltage: 0 sec

Low Voltage: 0 sec

High GF Current: 0 sec

High Load Current: 0 sec

Low Load Current: 0 sec

High Tracing Resistance: 0 sec

Low Tracing Resistance: 0 sec

Alarm Filters Other ◀ ▶

Back Apply

Figure 10 4: Electrical Settings / Alarm Filters screen

The Electrical Settings Alarm filters

The use of Alarm filters minimizes nuisance alarms by forcing the NGC-20 to verify that the Alarm condition continually exists over the selected period of time before the alarm is being indicated and the alarm relay acts. Alarm filters are provided for: high and low voltage alarms, high and low heater current alarms, high ground fault current alarms, high and low tracing resistance. There is no alarm filter provided for ground fault tip alarms since this sort of alarm requires immediate action.

Tapping on the field after the Alarm filter name will open a selection screen. Only filter times as shown on the screen can be selected.

High Voltage

1 2 3

4 5 6

7 8 9

10 11 12

0

Cancel

Figure 10 5: Electrical Settings / Alarm Filters values

Once the field containing the desired value is tapped then the screen will close and you will be brought back to Figure 10 4. When all filter times are entered then tap **Apply** to confirm the new settings. Click on **Back** to return to previous screen Figure 11 1: NGC-20 Configuration Screen

Electrical Settings (Other)

Electrical Settings

Nominal Tracing Resistance:

6.0 Ω

High Tracing Deviation:

50%

Low Tracing Deviation:

50%

Alarm Filters Other ◀ ▶

Back

Apply

Figure 10 6: Electrical Settings /Other

The Electrical Settings Other allows the following variables to be adjusted:

Nominal Tracing Resistance: this field contains the calculated value of the tracing resistance. (Ohmic) Enter the nominal tracing resistance via the numeric pad and confirm the new settings by tapping **Enter**.

High Tracing Deviation (%): if the calculated tracing resistance deviates more than x% an alarm will be generated. Use the numeric keypad to enter the desired value and confirm new settings by tapping **Enter**.

Low Tracing Deviation (%): if the calculated tracing resistance deviates more than x% an alarm will be generated. Use the numeric keypad to enter the desired value and confirm new settings by tapping **Enter**.

Tap Apply to confirm. Tap on Back to go to the NGC-20 Configuration screen.

11. SIL 2 SAFETY TEMPERATURE LIMITER SETTINGS

The next section shows how to configure the DigiTrace NGC-20 SIL 2 approved Safety Temperature Limiter. Use this limiter to prevent heating applications from overheating. The NGC-20 Safety Temperature Limiter is approved for use in Hazardous area Zone 1, Zone 21, Zone 2 and Zone 22

NGC-20 Configuration

Controller Settings

Temperature Settings

Temp. Source Settings

Electrical Settings

Safety Limiter

Maintenance

Alarm Masks

Back

Figure 11 1: NGC-20 Configuration Screen

Tap on **Temperature Limiter** to open the Limiter configuration screen.

Limiter Parameters

Safety Limiter Parameters

Firmware:
2.0

Safety Limiter Status:
Tripped

Safety Limiter Temperature:
117°C

Safety Limiter Setpoint
457°C

Reset Tripped Safety Limiter

Trip Safety Limiter

Back

Figure 11 2: Limiter Parameters

Firmware:

This field shows the actual firmware revision of the Safety Temperature Limiter.

Safety Limiter Status:

This field shows the actual status of the Safety Temperature Limiter.(Normal operation, Tripped, Latch Temporarily Disabled)

Safety Limiter Temperature:

Shows the temperature actually being measured by the Limiter RTD. If this value surpasses the Safety Limiter set point the Safety Limiter Will Trip Open. Once the Safety Limiter has tripped a manual intervention will be required to Reset / Rearm the Safety Temperature Limiter. Resetting the safety Temperature limiter will be only possible after all process conditions have returned to a safe state. (The Limiter Temperature has dropped below the Limiter Temperature Set point.

Safety Limiter Temperature Set point:

This field holds the Safety Limiter set point. This value should be chosen in accordance with the Temperature Class of the area in which the heating application is installed (T-class T4, T3, T2) or the maximum surface temperature allowed for the heating device assuming this is a lower temperature.

Since the Safety Temperature Limiter is a safety device it requires a special procedure to write a new set point to the Temperature limiter. Tap in the Limiter Temperature Set point field to start the write procedure. This will open a new screen

Limiter Setpoint

Safety Limiter Cut-Out

123 °C

Min: -60 Max: 599

7	8	9	Clear
4	5	6	Cancel
1	2	3	Enter
0	.	-	+

Figure 11 3: Safety Limiter Cut-Out

Enter the new set point via the numeric pad. Hit Enter to confirm the new Limiter Cut-Out set point. This will open a new screen: Figure 11 4: (writing a new) Safety Limiter Cut-Out.

Limiter Set point

Safety Limiter Setpoint

Press Safety Limiter
Set Button In
NGC-20 Hardware

Current Safety
Limiter Setpoint: 123°C

Desired Safety
Limiter Setpoint: 12°C

Number of Polls: 7

Cancel

Figure 11 4: (writing a new) Safety Limiter Cut-Out

From this point onward the NGC-CMA device will send the new set point at regular intervals to the DigiTrace NGC-20 hardware (Polling). The polling process will be repeated until the process is cancelled or until the Safety Limiter Set button inside the unit is pressed. **Press and hold the button for 3 seconds.**

The Display of the DigiTrace NGC-20 will flash briefly and show actual and new limiter cut out temperature.

The Safety Limiter Temperature Set button is the Black Push button on the left-hand side of the DigiTrace NGC-20 hardware as is shown on Figure 11 5 below.




Figure 11 5: location of limiter temperature set button and Limiter Reset button inside the DigiTrace NGC-20 control unit enclosure.

Limiter Set point

Safety Limiter Setpoint

Press Safety Limiter
Set Button In
NGC-20 Hardware



Number of Polls: 5

Cancel

After the new set point has been successfully updated a pop up message as shown in Figure 11 6 will appear confirming the new set point has been successfully updated.

Note: that the new set point may differ 1 or 2 degrees from the selected values. This is caused by rounding up or rounding down the set point while it is been converted by the internal electronics.

Figure 11 6: Limiter cut out temperature updated successfully.

11.1. Resetting the Safety Temperature Limiter

Once the safety Temperature limiter has tripped it will need to be reset in order to restore normal operation. Resetting the Safety Temperature limiter will only be possible after safe operating conditions have returned. See Figure 11 5 in order to locate the RESET button.

Reset protection Password

Enter 547 to continue

<input type="text"/>			
Min: 100	Max: 999		
7	8	9	Clear
4	5	6	Cancel
1	2	3	Enter
0	.	-	+

Resetting the Safety Temperature Limiter is a safety Function therefore the Reset operation is protected by a password in order to prevent the Safety Temperature limiter from being reset unintentionally.

The Safety temperature Limiter can be reset from the DigiTrace NGC-CMA. In order to do so, tap on **Reset Tripped Limiter** doing this will open a new screen as is shown in Figure 11 7

Use the numeric Key pad to enter the number shown in blue on the top of the screen and tap enter

Figure 11 7: Resetting – rearming the Safety temperature Limiter

Successfully Reset Tripped Limiter



Figure 11 8: Resetting – rearming the Safety temperature Limiter

If the number entered was correct than the Safety Limiter will Reset and a pop up screen will appear

The pop up screen confirms the Safety temperature Limiter has been successfully reset.

Tap OK when done.

11.2. Trip Limiter - Test function for SIL approved Safety Temperature limiter

This is the test function of the SIL 2 approved Safety Temperature limiter.

Limiter Parameters (Trip Limiter)



Figure 11 9: Limiter cut out temperature updated successfully.

This is the test function of the SIL 2 approved Safety Temperature limiter. Hit this field in order to Test the safety Temperature limiter at regular intervals at least once every year.



Figure 11 10: Successfully tripped safety temperature limiter

When tripped a screen will pop up confirming that the Safety Temperature Limiter has tripped successfully.

In order to rearm the safety temperature limiter follow the procedure as explained in paragraph 11.1 Resetting the Safety Temperature Limiter.

Tap on **Back** when done. This will bring you back to the NGC-20 Configuration Screen (Figure 11 1).

12. MAINTENANCE DATA

The Maintenance data screens provide the possibility to look at Minimum and Maximum values of recorded data. While controlling the DigiTrace NGC-20 control unit measures many variables such as; voltage, current, temperature, ground fault etc.. and for each of these the highest and lowest value ever measured is stored in the DigiTrace NGC-20 controllers memory. The Maintenance screens of the NGC-CMA enable to visualise and to reset this data.

Note: Maintenance data is stored until it is manually reset. After resetting the measuring process starts new and stores new Min / Max values until the next reset. Tap Maintenance Data in order to continue.

NGC-20 Configuration

Controller Settings

Temperature Settings

Temp. Source Settings

Electrical Settings

Temperature Limiter

Maintenance

Alarm Masks

Back

Figure 12 1: NGC-20 Configuration Screen

In total there are 6 screens showing maintenance data. The last option in Maintenance Screen 6 Forces the Factory defaults to be loaded in the DigiTrace NGC-20 control Unit.

Reset Maintenance (1)

Reset Maintenance

Control

Min. Temp: 13 °c

Max. Temp: 57 °c

Reset Control Temperatures

AC Voltage

Min. Voltage: 127 v

Max. Voltage: 233 v

Reset AC Voltage Max/Min

1

2

3

4

5

◀▶

Back

Figure 12 2: Maintenance data screen 1

Records are kept of: Control Temperature, AC Voltage

Reset Maintenance (2)

Reset Maintenance

Sensor 1

Min. Temp: 18 °c

Max. Temp: 18 °c

Reset Sensor 1 Temperatures

Sensor 2

Min. Temp: 15 °c

Max. Temp: 15 °c

Reset Sensor 2 Temperatures

2

3

4

5

6

◀▶

Back

Figure 12 3: Maintenance data screen 2

Sensor 1 Temperature

Sensor 2 Temperature,

Reset Maintenance (3)

Reset Maintenance

Highest Instantaneous Ground Fault
Reporting: 0 mA
Reset Highest Ground Fault

Highest Instantaneous Load Current
Reporting: 0.0 A
Reset Highest Load Current

2 3 4 5 6 ◀ ▶

Back

Figure 12 3: Maintenance data screen 2

Highest Ground Fault
Highest Load Current

Reset Maintenance (4)

Reset Maintenance

Contactor Cycle Count
Reporting: 0 cycles
Reset Contactor Cycle Count

Number of Hours In Use
Reporting: 0 hrs
Reset Number of Hours In Use

2 3 4 5 6 ◀ ▶

Back

Figure 12 5: Maintenance data screen 4

Contactor Cycle count
Number of hours in use

Reset Maintenance (5)

Reset Maintenance

Heater On-Time
Reporting: 0 hrs
Reset Heater On-Time

Power Accumulator
Reporting: 0 kW-hr
Reset Power Accumulator

2 3 4 5 6 ◀ ▶

Back

Figure 12 6: Maintenance data screen 5

Heater On Time
Power Accumulator

Reset Maintenance (6)

Reset Maintenance

Temperature Limiter

Min. Temp: 15 °c

Max. Temp: 103 °c

Reset Limiter Max/Min Temps.

Force User Config. Defaults

3 4 5 6 7

Back

Figure 12 7: Maintenance data screen

Safety Limiter Min / Max temperatures

Forces the Factory defaults to be loaded in the connected DigiTrace NGC-20 control Unit.

Tap on Back when done. This will bring you back to the NGC-20 Configuration Screen (Figure 12 1).

12.1. Force User Configuration Defaults.

Tapping on this field will force the factory defaults to be loaded in the connected DigiTrace NGC-20 control Unit.

Reset Maintenance (Forcing Factory Default settings)

Reset Maintenance

Temperature Limiter

Min. Temp: 15 °c

Max. Temp: 103 °c

Reset Limiter Max/Min Temps.

Force User Config. Defaults

3 4 5 6 7

Back

Figure 12 7: Maintenance data screen

Tapping on the field Force User Config. Defaults will force the factory defaults to be loaded in the connected DigiTrace NGC-20 control Unit.

Force User Defaults

Force User Defaults

Are you sure you want to Force User Config Defaults?

This will reset setpoints and other user settings back to their default configuration.

No Yes

Fig 8.8 Reset Maintenance – Confirm to load factory defaults.

Tap **Yes** or **No**

Note: that this function will override all customised settings and that they will be lost. After tapping Yes the field will briefly colour green as confirmation that the factory defaults are being loaded.

13. ALARM MASKS

The Alarm Mask defines which alarms will be enabled and which Alarms will be disabled. In order to enable an alarm just check the checkbox in on the left side of the screen. Before alarms will be generated they need to be enabled.




Figure 13 1: NGC-20 Configuration Screen

In total there are 4 screens with Alarm Masks. Alarms preceded by the ✓ checkmark are enabled.

Alarm Masks (1)

Alarm Masks

☒ Control Temperature Failure

☐ Control Temperature High

☒ Control Temperature Low

☐ Temperature Sensor 1 Failure

☐ Temperature Sensor 1 High

☐ Temperature Sensor 1 Low

☐ Temperature Sensor 2 Failure

☐ Temperature Sensor 2 High

☐ Temperature Sensor 2 Low

☒ Heater Time

1

2

3

4

Back

Apply

Tap **Yes** or **No**

Note: that this function will override all customised settings and that they will be lost. After tapping Yes the field will briefly colour green as confirmation that the factory defaults are being loaded.

Figure 13 2: Alarm Masks Screen 1

Alarm Masks (2)

Alarm Masks

☐ Temperature Source 1 Failure

☐ Temperature Source 2 Failure

☐ Temperature Source 3 Failure

☐ Temperature Source 4 Failure

☐ Temperature Source 5 Failure

☐ Temperature Source 6 Failure

☐ Temperature Source 7 Failure

☐ Temperature Source 8 Failure

☐ High Load Current

☒ Low Load Current

1

2

3

4

Back

Apply

Figure 13 3: Alarm Masks Screen

Alarm Masks (3)

Alarm Masks

- ☐ High Voltage
- ☐ Low Voltage
- ☐ High Tracing Resistance
- ☐ Low Tracing Resistance
- ☐ Device Reset
- ☒ User Configuration Lost
- ☒ Load Shed Source Failure
- ☒ Ground Fault Trip
- ☒ Ground Fault CT Failure
- ☒ High Ground Fault Current

1 2 3 4

Back Apply

Figure 13 4: Alarm Masks Screen 3

Alarm Masks (4)

Alarm Masks

- ☒ Switch Failure
- ☒ High Limit Temperature Cut-Out
- ☒ Contactor Cycle Count

1 2 3 4

Back Apply

Figure 13 5: Alarm Masks Screen 4

Tap on the **Back** button when done. This will bring you back to Figure 13 1: NGC-20 Configuration Screen

14. DIGITRACE NGC-20 MONITORING SCREENS

Besides its function as a programming and configuration interface, the DigiTrace NGC-CMA can also be used to monitor DigiTrace NGC-20 units while they are in operation. When used in monitoring mode all process variables measured by the DigiTrace NGC-20 control units can be visualised on the DigiTrace NGC-CMA. Tap on the monitoring field to continue. This will open the first of a total of 6 available monitoring screens. You can use the Left / Right buttons on the bottom of the screen to cycle through the different screens.

The following parameters are permanently monitored:

Monitoring Screen 1

NGC-20 Monitoring

Control Temperature:
Reporting: 22 °C

Load Current:
Reporting: 0.0 A

Voltage:
Reporting: 235 V

Ground Fault Current:
Instantaneous: 0 mA

Safety Limiter Status:
Latch Temporarily Dis.

Safety Limiter Temperature:
Reporting: 46 °C

Back < >

Figure 14 1: NGC-20 Monitoring

Control Temperature: Shows the actual temperature used by the DigiTrace NGC-20 for control. Based on this temperature the output will be switched ON / OFF.

Load Current: current uptake of the load(s) connected to the control output of the DigiTrace NGC-20 control Unit.

Note: that the load connected to the daisy chain terminals will not be monitored.

Voltage: actual power supply voltage

Ground Fault Current: instantaneous ground fault current

Limiter Status: shows actual limiter status.

Limiter Temperature Reporting: this field shows the actual limiter temperature measured by the Limiter RTD.

Monitoring Screen 2

NGC-20 Monitoring

Test Tracing:

Reporting: Disabled

Voltage:

Reporting: 222 V

Max: 235 V

Min: 184 V

Last On: 222 V

Load Current:

Reporting: 0.0 A

Highest Ever: 0.3 A

Tracing Resistance:

Reporting: 8000.0 Ω

Figure 14 2: NGC-20 Monitoring

Test Tracing: tapping on the Start / Stop field will open the numeric key pad. Enter here a number x. After tapping on Enter the output of the DigiTrace NGC-20 will close, turning the connector heater on for x amount of seconds.

Voltage: this shows the actual voltage and the highest / lowest voltage that the unit has recorded since the last reset. For resetting these values go to the Maintenance screens as explained elsewhere in this manual.

Load Current: this field shows the actual load current and the highest current the unit has ever seen since the last reset. To reset these values go to the Maintenance screens.

Tracing Resistance: this field shows the actual calculated tracing resistance. (Calculated by dividing the measured supply voltage by the measured current) a value of 8000 Ohms means there is no load connected.

Monitoring Screen 4

NGC-20 Monitoring

Control Temperature:

Reporting: 15°C

Max: 17°C

Min: 13°C

Last On: 15°C

Sensor 1 Temperature:

Reporting: 15°C

Max: 37°C

Min: 9°C

Sensor 2 Temperature:

Reporting: 13°C

Max: 18°C

Min: 13°C

Figure 14 4: NGC-20 Monitoring

Control Temperature:

This is the temperature used by the DigiTrace NGC-20 controller to steer the output switch. This can be either the temperature measured by Temperature sensor 1, temperature sensor 2, the average or the lowest of both readings.

Max / Min are showing the highest and lowest reading recorded since the last reset. The value last on was the control temperature of the DigiTrace NGC-20 when the output was switched ON the last time.

Sensor 1 Temperature:

This field shows the actual temperature measured by temperature sensor 1. Max / Min are showing the highest and lowest reading recorded since the last reset.

Sensor 2 temperature:

This field shows the actual temperature measured by temperature sensor 2. Max / Min are showing the highest and lowest reading recorded since the last reset.

Monitoring Screen 5

NGC-20 Monitoring

Source Temperatures:

1: 35°C

2: Not Used

3: Not Used

4: Not Used

5: Not Used

6: Not Used

7: Not Used

8: Not Used

Contactor Cycle Count:

Reporting: 9665

Figure 14 5: NGC-20 Monitoring

Source Temperatures:

This field shows all actual tensor temperatures presently connected. Temperature sources 3 to 8 require the use of an optional NGC-UIT and MONI-RMM2 device.

Contactor Cycle Count:

This field gives the actual number of switch operations the output switch has performed since the last reset.

Monitoring Screen 6

NGC-20 Monitoring

Safety Limiter Status:

Latch Temporarily Dis.

Safety Limiter Temperature:

Reporting: 44 °C

Max: 200 °C

Min: 19 °C

Highest Ever: 200 °C

Lowest Ever: 19 °C

Number of Hours:

Since Reset: 3

In Use: 147

Heater Time:

Reporting: 95 hrs



Figure 14 6: NGC-20 Monitoring

Limiter Status

This field shows the actual state of the Safety temperature limiter of DigiTrace NGC-20-CL-E units.

Limiter Temperature

These fields are showing temperature information measured by the limiter temperature sensor RTD 3.

Reporting: actual measured temperature

Max: maximum temperature ever measured since last reset.

Min : minimum temperature ever measured since last reset

Number of hours:

Since Reset: This feature indicates the total hours of use of the controller since the last reset (power cycle). The number of hours since last reset hours accumulator can only be reset by cycling the controller's power.

Note: The Number of hours since last reset will roll over to zero when the upper limit of 65,535 hours has been exceeded.

In Use: The purpose of this feature is to indicate the total hours of use of the controller since its initial operation.

Note: The Hours in use accumulator value will roll over to zero when the upper limit of the accumulator has been exceeded. This limit is 4,294,967,295 hours.

Heater Time

Total time the heater has been energised since it was last reset (power cycle).

Tap on the Back button when done. This will bring you back to the NGC-20 Main Screen.

NGC-20

Tag:

NGC-20-1

Firmware: 3.14.13

Configure

Monitor

View Alarms

Firmware/Settings

Back

Figure 14 7: NGC-20 Main screen

15. DIGITRACE NGC-20 ALARM SCREENS.

Tap on the View Alarms screen in order to investigate and eventually reset actual alarms. In the Active Alarms field all alarms are shown. In the example below only one Limiter Trip Alarm is present.

NGC-20 Alarms	
<div><div>NGC-20 Alarms</div><div>Active Alarms</div><div>Safety Limiter Trip Alarm</div><div></div><div>Reset Selected Alarm</div><div>Reset All Alarms</div><div>Back</div></div> <div>Figure 15 1: NGC-20 Alarms Screen</div>	<p>In order to reset an alarm select the alarm by tapping on that specific alarm in the Active alarms window and then hit Reset Selected Alarm. The Reset All Alarms button resets all actual alarms in a single operation.</p> <p>Note that Alarms can only be reset after the event causing the alarm has been resolved or the measured value has changed such that the actual reading is within the alarm boundaries</p>

Example: a low temperature alarm can only be reset when the temperature has increased to a value above the low temperature alarm set point as shown in Figure 9-5: Temperature Settings Control screen.


Figure 9 5: Temperature Settings: Control screenAfter the alarms are reset than hit the Back button to go back to the main screen



Figure 15 2: NGC-20 Main screen

16. FIRMWARE / SETTINGS (COMMUNICATION SETTINGS)



Tap on the Firmware/Settings button as presented on Figure 8 2.



16.1. Upgrading firmware of the DigiTrace NGC-20 control unit

The Firmware / Settings function allows you to install new revisions of DigiTrace NGC-20 firmware in the controller via the NGC-CMA and the wireless Bluetooth interface. This procedure can be performed on units while they are in operation. During the firmware upload process the DigiTrace NGC-20 unit will be out of service for about 2 minutes. For safety reasons the output of the controller will be off during the entire upgrade process.

In the screen of Figure 16 1 tap on the Update Firmware button to initiate the process. This will open the Firmware update screen.



Firmware Update




Figure 16 4: Uploading Firmware

After the new file is selected hit **Upload** to start the upload process.

The old Firmware version as well the as the new Firmware are shown on the DigiTrace NGC-CMA screen

The installation procedure will remove the existing version and install new software in the DigiTrace NGC-20 control unit.

The installation progress can be followed on the **Progress** bar and on the installation progress timer.

Once the upload process is complete the DigiTrace NGC-20 control unit will briefly show the Firmware version number on the display and return to normal operation.

Firmware Update (Complete)




Figure 16 5: Firmware update complete

If the installation was successful a pop up window will appear confirming the firmware update was successful.

Confirm this pop up by tapping **OK**. This will close the Firmware upload process and return to the screen of Figure 16 4. Tap **Back** to close this window. Doing this will bring you back to Figure 16 1.

16.2. Changing the serial interface settings of the DigiTrace NGC-20 control unit

Firmware Update (Complete)




Figure 16 6: Firmware / Settings screen

Tap on **Com Parameters** to open the Communication Parameters screen.

Com Parameters

The screenshot shows a screen titled "Com. Parameters" with the following settings:

- Modbus Address: 3
- Baud Rate: 9600
- TX Delay: 20 ms
- Frame Type: ☒ RTU, ☐ ASCII
- Data Bits: ☒ 8, ☐ 7
- Parity: ☒ No, ☐ Odd, ☐ Even
- Stop Bits: ☐ 1, ☒ 2
- Buttons: Back, Apply

Figure 16 7: Communication Parameters

The Com. Parameters screen allows users to configure the communication settings of DigiTrace NGC-20 control units.

Modbus Address: the Modbus address needs to be unique on the DigiTrace NGC-20 network. The Modbus address can have any value from 1 to 247. 247 is the maximum number of DigiTrace NGC-20 units which can be connected to one RS-485 serial communications port.

Baud Rate: This field allows you to select the baud rate of the external communication port.

Selections: 2400, 4800, 9600, 19200, 38400, 57600. Default : 9600

Transmit Delay Entry Window (TX Delay)

This field sets the time the NGC-UIT will wait after it receives a message before it replies.

Range: 0–1000 milliseconds, Default : 20 ms

Other defaults are: Frame Type = RTU, 8 Data bits, No Parity and 2 stop bits.

These settings may have to be adjusted in order to set up communication between DigiTrace NGC-20 control units and non Pentair Thermal Management Host systems like PLC 's

Tap on the Back button in order to leave this screen and to go back to figure 12.1

16.3. DigiTrace NGC-20 Display Test.

The field NGC-20 Display Test will initiate a display test of the DigiTrace NGC-20 Control unit's display. Tap on the Back button when done.

16.4. DigiTrace NGC-20 Mode settings

The field NGC-20 Mode will offer the option to switch the mode of the NGC-20 controller.

If the controller is used in combination with an UIT select "Mixed Mode"


In all other cases select "Standard Mode"

17. USING THE DIGITRACE NGC-CMA IN MIXED MODE


When operated in mixed mode the feature set of the NGC-CMA is adapted to the level of the NGC-UIT. This means that a number of features as shown in the first part of the operation manual will be hidden in mixed mode. The following pages will focus on the features supported in mixed mode only. DigiTrace NGC-20 units will automatically detect in which mode they are operated (stand alone, in a network with DigiTrace Supervisor or in a mixed mode system together with an NGC-UIT) the general operation and use of the NGC-CMA remains unchanged.

17.1. Initial Setup of the unit in Mixed Mode


After the program is started the start up screen will be visualised. The start up screen allows users to configure the unit to their personal needs and process requirements.

DigiTrace Configuration Utility Main screen	
 <p>Figure 17 1: Startup screen</p>	<p>The Tab "Configure" initiates the Bluetooth device discovery process.</p> <p>The tab "Settings" allows setting the Language, Temperature units, and About shows the software revision.</p> <p>The tab "Exit" closes the application.</p> <p>Begin the initial configuration by tapping on Settings on the start up screen. This will open the Setup screen as shown in Figure 17 1.</p>


18. CHANGING MAIN SETTINGS OF THE USER INTERFACE SCREENS

Setup	
 <p>Figure 18 1: Setup Screen</p>	<p>About: shows the software version of the DigiTrace Configuration Utility Software.</p> <p>Languages: Allows selecting a convenient language of the user interface software.</p> <p>Temperature Units: Sets the temperature units of the DigiTrace NGC-CMA. Supported are: degrees Celcius and degrees Fahrenheit. The default is Celsius.</p> <p>Back: Return to previous screen.</p>

18.1. Languages


Setup	
 <p>The screenshot shows the 'Select Language' screen with four buttons: English, Français, Deutsch, and Cancel.</p> <p>Figure 18 2: Language Selection Screen</p>	<p>Tap on Languages in Figure 18 1 to select your language.</p> <p>Supported languages are: English (default) French (Français) German (Deutsch)</p> <p>After tapping on the desired language, the Application will close and will need to be restarted manually.</p> <p>Remark: selecting a different language will cause the unit to reboot. Allow enough time for the unit to reboot and then revert back to step 1 in order to restart the application. The application will now run in the selected language.</p>

18.2. Temperature units

Temperature Units	
 <p>The screenshot shows the 'Temperature Units' screen with three buttons: Celsius, Fahrenheit, and Cancel.</p> <p>Figure 18 3: Temperature Units Screen</p>	<p>From the Setup Screen as shown in Fig 1.3 tap on Temperature Units to change the way in which temperatures will be displayed on the NGC-CMA screens. The factory default setting is °C.</p> <p>Tap on the desired units of measure degrees Celsius or degrees Fahrenheit. The screen will return automatically when the new unit has been selected.</p> <p>Tap on Cancel to return to the Startup Screen</p>

19. ESTABLISHING CONNECTION BETWEEN THE DIGITRACE NGC-CMA AND DIGITRACE NGC-20 CONTROL UNITS

The following pages will explain how to configure DigiTrace NGC-20 units from the NGC-CMA handheld programmer.

DigiTrace Configuration Utility Main Screen	
 <p>The screenshot shows the 'DigiTrace NGC Configuration and Monitoring Assistant' main screen with three buttons: Configure, Settings, and Exit.</p> <p>Figure 19 1: Main Screen</p>	<p>Tap on Configure (Figure 19 1). The display will now show the Bluetooth discovery screen and the device discovery process will be started.</p>

Bluetooth Discovery Process

Bluetooth Discovery

Please wait,
Discovering devices...



Back

Continue

Figure 19 2: Bluetooth Discovery screen – Searching for devices

In background the device will scan for all DigiTrace NGC-20 controllers which are within range of the Bluetooth communications. Ensure that all NGC-20 units are powered up.

Bluetooth Discovery Process (device inventory)

Bluetooth Discovery

Please select the device you
wish to connect to

NGC-20-1



Scan for Devices

Back

Continue

Figure 19 3: Bluetooth Discovery screen – one device found

When searching is complete, devices in range will be listed on the screen.

Example: For this example, the only device that is found is NGC-20-1. If more than one

DigiTrace NGC-20 control unit is in range all units will be listed on the screen as shown in Figure 19 4

Bluetooth Discovery Process (selecting device)

Bluetooth Discovery

Please select the device you
wish to connect to

NGC 20-1

NGC 20-2



Scan for Devices

Back

Continue


Figure 19 4: Bluetooth Discovery screen – finding multiple devices.

Select the device to be connected by tapping on the device name. When a device is selected the background colour will become black. (See NGC-20-1). Tap on **Continue** to go on to the Main Screen.

If devices are not showing up move closer to the DigiTrace NGC-20 unit and repeat the scanning process by tapping on **Scan for Devices** once more. This will re-launch the device discovery process.


20. CONFIGURING DIGITRACE NGC-20 CONTROL UNITS

In order to configure the connected DigiTrace NGC-20 control unit tap on Continue

DigiTrace NGC-20 Main Configuration Screen	
 <p>Figure 20 1: NGC-20 Main screen</p>	<p>The NGC-20 main screen supports different options as shown in Figure 20 1.</p> <p>Configure: to configure the selected unit.</p> <p>Monitor: to monitor all process variables as currently active on this unit. All measured sensor temperatures, control temperature, load current, supply voltage, ground fault current and the status of the safety limiter.</p> <p>View Alarms: shows an overview of all active alarms and to reset alarms.</p> <p>Firmware / Settings: to install a new version of firmware in the selected controller.</p> <p>Back to go back to the Bluetooth discovery screen. From here a different DigiTrace NGC-20 unit can be selected for configuration.</p>

20.1. Changing the NGC-20 controller settings

Tap on Configure in the NGC-20 Main screen. As a result of this the NGC-20 Configuration screen will be shown. The NGC-20 configuration screen supports different options.

DigiTrace NGC-20 Configuration Screen	
 <p>Figure 20 2: NGC-20 Configuration screen</p>	<p>Use Controller Settings to alter; set points, control mode, dead band, the device tag and load shedding.</p> <p>Use Temperature Settings to alter High and Low Temperature alarm values, the temperature alarm filter, fail safe mode and to enable and preset the high limit Cut-Out</p> <p>Use Electrical Settings in order to set the high and low load current and voltage alarm values. The second screen offers the possibility to load the relay cycles time counter and to adjust the ground fault alarm warning and trip level.</p> <p>Use Safety Limiter; use this entry in order to control the Safety temperature limiter setpoint, trip and reset the Safety temperature limiter after it has tripped.</p> <p>Use Maintenance to get information about the minimum and maximum values recorded by the unit. Of the following variables the minimum and maximum are stored; control temperature, AC Voltage, ground fault current, load current, relay cycle count, heater hours in use time and the safety limiter temperatures.</p> <p>Back returns to the Main Screen (Figure 20 1).</p>

20.2. Changing the Temperature set point of a DigiTrace NGC-20 control unit

Tap on Controller Settings. This will open a next screen showing the actual Controller settings. In order to change any of the values tap on the field holding the actual variable.


Controller Settings.	
 <p><i>Controller Settings</i></p> <p>Temperature Setpoint: 10°C</p> <p>Mode: On/Off</p> <p>Deadband: 3°C</p> <p>1 2 Load Shedding ◀ ▶</p> <p>Back Apply</p>	<p>Tap on the field holding the actual value (10°C) A numeric key pad as shown in Figure 20 4 will pop up.</p>

Figure 20 3: Controller Settings – Settings 1 screen


Numeric Input Screen (Temperature Set point)	
 <p><i>Temp Setpoint</i></p> <p>10 C</p> <p>Min: -80 Max: 700</p> <p>7 8 9 Clear</p> <p>4 5 6 Cancel</p> <p>1 2 3 Enter</p> <p>0 . - +</p>	<p>Enter the desired temperature set point by tapping on the screen and press Enter to complete.</p> <p>- This example shows a Temp Set point of 10°C. By pressing enter the screen will return to the Controller Settings screen (Figure 20 3).</p> <p>REMARK: The numeric screen is used at various places throughout this manual everywhere where numeric values are to be changed or entered.</p>

Figure 20 4: Temp Set point Numeric Screen

20.3. Changing the Switch control mode

To change the control mode select the Mode on the Controller settings page (Figure 21 2).


Switch Control Mode	
 <p><i>Switch Control Mode</i></p> <p>On/Off</p> <p>PASC</p> <p>Always On</p> <p>Always Off</p> <p>Cancel</p>	<p>The switch control mode defines how the output switch will be operated in order to maintain the desired temperature. Tap on the desired Switch Control Mode. The DigiTrace NGC-20 supports a number of different control modes as shown in Figure 20 5.</p> <p>The different control modes supported are:</p> <ul style="list-style-type: none"> ▶ ON/OFF ▶ PASC ▶ Always ON ▶ Always Off ▶ Cancel <p>Note that depending on the selected control mode the input fields in the previous and next screens will vary.</p> <p>Cancel will return to the Controller Settings screen.</p>

Figure 20 5: Control Mode settings Screen

Controller Settings 1 (Deadband)

Controller Settings

Temperature Setpoint:
10°C

Mode:
On/Off

Deadband:
3°C

1 2 Load Sheddli ◀ ▶

Back Apply

Figure 20 6: Controller Settings 1

ON/OFF is a simple set point / dead band operation.

Set in the **Dead band** Field the desired dead band.

Note that the Dead band will be above set point.

Example: a set point of 40°C and dead band of 5 will turn the heating off at 45 °C and on at 39°C

Controller Settings 1 (PASC)

Controller Settings

Temperature Setpoint:
10°C

Mode:
PASC

PASC Min Ambient Temp:
-40°C

PASC Min Pipe Size:
1.3 cm

Power Adjust:
100 %

1 2 Load Sheddli ◀ ▶

Back Apply

Figure 20 7: Controller Settings 1

PASC takes advantage of the fact that the heat loss from a pipe is proportional to the temperature difference between the pipe and the ambient air. This is true regardless of heater type, insulation type, or pipe size. Once the heat tracing and insulation on a pipe has been designed to balance heat input with heat loss and maintain a particular temperature, the main variable in controlling the pipe temperature becomes the ambient air temperature. The DigiTrace NGC-20 has a control algorithm that uses the measured ambient temperature, desired maintain temperature, minimum ambient temperature assumption used during the design stage, and size of the smallest pipe diameter to calculate how long the heater should be on or off to maintain a near-constant pipe temperature.

PASC Min Ambient Temp: this is the minimum expected ambient temperature which is expected for this area. This information is part of the design information and is country and region specific.

PASC Min Pip Size: this is the diameter of the smallest diameter of any pipe controlled by the heating circuit / DigiTrace NGC-20 control unit.

The **Power Adjust** (min 10% to Max 200%) The Power adjustment factor can be used to influence or override the calculated ON /OFF ratio. Values in excess of 100% will lead to more heat, values below 100% will reduce the temperature.

Apply confirms new settings.

Controller Settings 1 (Force ON / Force OFF)

Controller Settings

Temperature Setpoint:
10°C

Mode:
Always Off

1 2 Load Sheddli ◀ ▶

Back Apply

Figure 20 8: Controller Settings 1

Always On The relay output is permanently switched on (user override), turns on the power to the heater and leaves it on.

Always OFF The relay output is permanently switched off (user override), turns off the power to the heater, and leaves it off.

Note: consider to monitor the pipe temperatures for Low / High temperature alarms when selecting Force ON or Force OFF control mode.

Tap **Apply** after the desired control mode has been selected.

20.4. Changing DigiTrace NGC-20 device tag name

Controller Settings 2 DigiTrace NGC-20 Tag:

Controller Settings

NGC-20 Tag:

ID 1

12Load Sheddlt

BackApply

Figure 20 9: Controller Settings – Settings 2 screen.

This screen allows you to change the DigiTrace NGC-20 device tag. Tags can be 39 characters in length and may contain all numeric characters. Enter the desired Tag for the DigiTrace NGC-20 device by tapping in the actual device tag or elsewhere in that field.
(NGC-20-1)

NGC-20 Tag

NGC-20 Tag

pipe 1

CancelOK

1234567890-+=

Tabqwertyuiop[]

CAPasdfghjkl;'

Shiftzxcvbnm,./←

Ctrläü*|_↓↑↵→

Figure 20 10: NGC-20 Tag

Enter the desired Tag by using the onscreen keyboard. Tap OK when finished.

- For this example, the new tag will be "Pipe #1".

20.5. Load Shedding

Load shedding is a control mode that can be programmed and initiated only by an external communicating device, which overrides temperature control and forces the output of the controller OFF until the override is removed. When using an external device (DigiTrace Supervisor Software or a DCS), a load shedding command is continually broadcast over the communications network.

When power is applied, the controller delays energising its trace by 'x' number of seconds, where 'x' is equal to the last digit in its network address. If the load shed function is enabled, the controller will go into load shed mode before it turns its output on. It will then look for the broadcasted load shed command. If the controller receives the load shed command before it times out, it will remain in load shed mode, and the output will remain off as long as the module receives a regular broadcast of the command. If the controller does not receive the load shed command within the timeout period, it will energise its output and resume normal operation. The timing of this broadcast (and the timeout value) can vary between 30 seconds and 10 minutes. A total of 16 different Load shedding zones can be defined.

48

Load Shedding 1

Controller Settings

- ☐ Shedding Enabled
- ☐ Shedding Fail-Safe Enabled
- ☐ Zone 1 Shedding Enabled
- ☐ Zone 2 Shedding Enabled
- ☐ Zone 3 Shedding Enabled
- ☐ Zone 4 Shedding Enabled
- ☐ Zone 5 Shedding Enabled
- ☐ Zone 6 Shedding Enabled
- ☐ Zone 7 Shedding Enabled

Load Shedding 1 Load ◀ ▶

Back Apply

Figure 20 11: Controller Settings, Load Shedding 1

If a load shedding command is present, the controller will continue to hold the output OFF, until one of two conditions occurs:

1. The zone definition flags of an external communicating device which initiated load shedding clears and the command to terminate load shedding mode is issued.
2. Communications are interrupted between the controller and its communicating device, as in the case of a damaged communications wire. If communication ceases for a specified timeout value, the controller will return to normal operation. The value for this timeout is programmable within the controller (30 seconds to 600 seconds).

Note: The controller will return to normal operation if communications between the external communicating device and the controller are disrupted in any way. This will return temperature control to the HTC. Also, the HTC does not perform a periodic autocycle test while operating in load shed mode.

Load Shedding 2

Controller Settings

- ☐ Zone 8 Shedding Enabled
- ☐ Zone 9 Shedding Enabled
- ☐ Zone 10 Shedding Enabled
- ☐ Zone 11 Shedding Enabled
- ☐ Zone 12 Shedding Enabled
- ☐ Zone 13 Shedding Enabled
- ☐ Zone 14 Shedding Enabled
- ☐ Zone 15 Shedding Enabled
- ☐ Zone 16 Shedding Enabled

Load Shedding 2 Load ◀ ▶

Back Apply

Figure 20 12: Controller Settings, Load Shedding 2

Three parameters must be set in the controller to configure it for load shedding operation:

1. The load shedding feature must be enabled.
2. The FAIL SAFE MODE parameter must be enabled or disabled depending on the application requirements. If FAIL SAFE MODE is enabled, then at least one LOW TS ALARM (of a TS used in the TS CONTROL MODE) must be enabled. If the alarm temperature exceeds the CONTROL SETPOINT temperature, fail-safe mode will be disabled.
3. The zone definition flags of an external communicating device that are to be associated with the load shedding action for the controller must be defined. The NGC40 controller will support up to 16 different zones.

These parameters can only be configured using an external communicating device connected to the bridge or DigiTrace UIT.

Notes:

- Fail-safe mode is always disabled if the SWITCH CONTROL MODE is set to either of the two proportional ambient control modes, or the TS CONTROL MODE = EXT INPUT, FAIL OFF/ON
- The HTC will turn on its output switch when the control temperature becomes less than the highest LOW TS ALARM temperature if the following conditions are met:
 - Fail-safe mode is enabled
 - Load shedding is active
 - The TS CONTROL MODE uses both TS 1 and TS 2
 - Both TS 1 and TS 2 have their LOW TS ALARMS enabled
- A FORCE ON override signal has higher priority than a load shedding signal. An INHIBIT signal has higher priority than fail safe mode.

Back button returns to the NGC-20 configuration screen.

21. DIGITRACE NGC-20 TEMPERATURE SETTINGS AND TEMPERATURE ALARMS

On the DigiTrace NGC-20 Configuration screen (Figure 21 1) tap on Temperature Settings.




Figure 21 1: NGC-20 Configuration screen

21.1. Changing NGC-20 Temperature sensor type (Sensor 1)

The first screen of the temperature settings screen enables configuration of the sensors. The DigiTrace NGC-20 control unit supports only one type of temperature control input (Pt 100 -3-wire)

Temperature Settings 1	
<div><p>Temperature Setup</p><p>High Temp Alarm: 149°C</p><p>Low Temp Alarm: -12°C</p><p>Temperature Alarm Filter: 900 sec</p><div><div>1</div><div>2</div></div><div><div>Back</div><div>Apply</div></div></div>	<p>High Temp Alarm (Min -80 to Max +700°C) Enter in this field the value at which - when exceeded - you want the DigiTrace NGC-20 control unit to generate a high temperature alarm. This High Temperature condition will be monitored by Temperature sensor T1 only.</p> <p>Low Temp Alarm (Min -80 to Max +700°C) Enter in this field the value at which - when exceeded - you want the NGC-20 control unit to generate a Low Temperature Alarm. This Low Temperature condition will be monitored by Temperature sensor T1 only.</p> <p>Temperature Alarm Filter (Min 0 to Max 59940 seconds) Can be seen as an alarm delay. This means that when the temperature drops below the Low Alarm Set point the DigiTrace NGC-20 Control unit will only trigger an alarm when the value entered in the Low Alarm Filter is timed out. This means that if immediate action of the alarm output is required, that the Low Alarm Filter value should be set at 0 sec. Any other value will result in a delay. The operation of the High Alarm Filter is the same.</p> <p>Tap on Apply to confirm your new settings. Tap Back when ready.</p>

Fig 17.1 Temperature Setup: screen 1

21.2. Fail Safe mode and High Limit Cut-Out Set point

The Fail safe mode defines the output of the DigiTrace NGC-20 output switch in case of a sensor failure. Tap on the entry field behind Fail Safe mode for more options.


Temperature Settings 2	
	<p>Fail Safe:</p> <p>In order to choose a Fail Safe mode tap on the field currently showing Power Off. The different Fail modes supported by the DigiTrace NGC-20 are: Power Off or Power On</p>

Figure 21 2: Temperature Setup: screen 2


Fail Safe	
	<p>Power Off: meaning that should the control sensor or control sensors of this DigiTrace NGC-20 unit fail the output switch will open. Use this for all circuits where keeping the heating cables permanently powered could cause overheating.</p> <p>Power On: meaning that should the control sensor or control sensors of this DigiTrace NGC-20 unit fail the output switch will be permanently close. This is the preferred option for freeze protection lines and most self-regulating heating systems.</p> <p>Choose the desired fail safe mode from the list by tapping on that field</p> <p>Cancel will bring you back to the previous screen as shown in Figure 21 2.</p>

Figure 21 3: Temperature Setup: Fail Safe Mode


Temperature Setup Screen 2	
	<p>The High Limit Cut-Out actually works as a temperature limiter which can be configured to operate as either a latching or non-latching type. When the Latching button is set to Enabled, each time an alarm has occurred the Alarm needs to be manually reset. When set to Disabled the alarms will be self-healing and will disappear when the alarm condition is no longer present.</p> <p>Confirm your new settings by tapping the Apply button. Tap Back when ready, doing this will bring you back to screen Figure 21 1</p>

Figure 21 4: Temperature Setup: screen 2

22. ELECTRICAL SETTINGS

To set up electrical settings click on Electrical Settings in the NGC-20 Configuration screen (Figure 21-1).




Figure 22 1: NGC-20 Configuration screen

Electrical Settings (Alarm Set points screen 2)	
The image shows the "Electrical Settings" screen. The title "Electrical Settings" is in blue. Below it are several input fields: "High Load Current:" with a value of "30.0 A", "Low Load Current:" with a value of "0.3 A", "High Voltage:" with a value of "270 V", "Low Voltage:" with a value of "90 V", and "Heater Time Alarm:" with a value of "100000 hrs". Below these fields are two tabs labeled "1" and "2". At the bottom are two buttons: "Back" and "Apply".	<p>The Electrical Settings Alarm Set points Screen 1 allows the following variables to be adjusted:</p> <p>High Load Current (Range Min 0.3 – Max 30A) The Load Current alarm will generate an alarm each time the Load Current supplied to the heating cable exceeds the defined band. The load current is the same as the heater current.</p> <p>Low Load Current (Range Min 0.3 – Max 30A) The Load Current alarm will generate an alarm each time the Load Current supplied to the heating cable exceeds the defined band. The load current is the same as the heater current.</p> <p>High and Low Voltage (Range Min 50 – Max 305 V AC) The voltage alarm will generate an alarm each time the power supply voltage supplying the NGC-20 control unit and the heating cables exceeds the defined band.</p> <p>Heater Time Alarm (Range Min 1 – Max 1.000.000 hrs) The Heater Time Alarm is an hour counter which record the actual time the output is closed and the heating cables are used since the last reset.</p> <p>Confirm the new settings by tapping on the Apply button. Back will return to Figure 22 1.</p>

Electrical Settings (Alarm Set points screen 2)

The screenshot shows the 'Electrical Settings' screen with the following fields and controls:

- Relay Cycle Alarm:** A text input field containing '500000 Cycles'.
- Ground Fault Alarm:** A text input field containing '20 mA'.
- Ground Fault Trip:** A text input field containing '30 mA'.
- Ground Fault Trip:** A dropdown menu currently set to 'Disabled'.
- 1 2**: A small control element with two tabs, '1' and '2', where '2' is selected.
- Back** and **Apply**: Two buttons at the bottom of the settings area.

Figure 22 3: Electrical Settings screen 2

The Electrical Settings

Alarm Set points Screen 2 allows the following variables to be adjusted:

Relay Cycle Alarm: (Range Min 0 – Max 2.000.000)

The **Relay Cycle Count** counts the number of switch operations the Control output of the NGC-20 has made since the last reset. Each switch operation will subtract one (1) from the value entered in the counter. When the counter runs empty an alarm will be generated.

Ground Fault Alarm: (Range Min 10 – Max 250 mA)

This field holds the value at which an early warning will be generated in the form of a High GF alarm. Typical value between 15 and 20 mA.

Ground Fault Trip: (Range Min 10 – Max 250 mA)

The **Ground Fault Trip Current** field holds the value at which a ground fault signal will trip the output permanently OFF. Typically GF Trip is set at a slightly higher value than the **Ground Fault Alarm setpoint**. Typical value is between 20 and 30 mA


Ground Fault Trip:


Enable / Disable. This selection activates or deactivates the Ground fault Trip Function. Selecting Disable here will deactivate the ground Fault Trip function so that in case of ground fault current only an alarm will appear.

Confirm the new settings by tapping on the **Apply** button. **Back** will return to Figure 22 1.

23. SIL 2 SAFETY TEMPERATURE LIMITER SETTINGS.

This paragraph shows you how to configure the DigiTrace NGC-20 SIL 2 approved Safety Temperature Limiter.

Electrical Settings (Alarm Set points screen 2)	
 <p>Figure 23 1: NGC-20 Configuration screen</p>	<p>Tap on Safety Limiter to open the Limiter configuration screen.</p>

Limiter Parameters	
 <p>Figure 23 2: Safety Limiter Parameters</p>	<p>Firmware: This field shows the actual firmware revision of the Safety Temperature Limiter.</p> <p>Safety Limiter Status: This field shows the actual status of the Safety Temperature Limiter.(Normal operation, Tripped, Latch Temporarily Disabled)</p> <p>Safety Limiter Temperature: Shows the temperature actually being measured by the Limiter RTD. If this value exceeds the Safety Limiter set point the Safety Limiter will trip open. Once the Safety Limiter has tripped a manual intervention will be required to Reset / Rearm the Safety Temperature Limiter. Resetting the safety Temperature limiter will only be possible once all process conditions have returned to a safe state. (The Limiter Temperature has dropped below the Limiter Temperature Set point.</p> <p>Safety Limiter Temperature Set point: This field holds the Safety Limiter set point. This value should be chosen in accordance with the Temperature Class of the area in which the heating application is installed (T-class T4, T3, T2) or the maximum surface temperature allowed for the heating device assuming this is a lower temperature.</p> <p>Since the Safety Temperature Limiter is a safety device it requires a special procedure to write a new set point to the Temperature limiter. Tap in the Safety Limiter Setpoint field to start the write procedure. This will open a new screen.</p>

23.1. Safety Limiter Setpoint

Safety limiter setpoint	
<div><p>Safety Limiter Cut-Out</p><div><div>457</div><div>°C</div></div><div><div>Min: -60</div><div>Max: 599</div></div><div><div>789</div><div>Clear</div></div><div><div>456</div><div>Cancel</div></div><div><div>123</div><div>Enter</div></div><div><div>0</div><div>.</div><div>-</div><div>+</div></div></div>	<p>Enter the new set point by tapping on the numeric pad. Hit Enter to confirm the new Limiter Cut-Out set point. This will open a new screen called Safety Limiter Cut-Out.</p>

Figure 23 3: Safety Limiter Cut-Out

Limiter Set point	
<div><p>Safety Limiter Setpoint</p><p>Press Safety Limiter Set Button In NGC-20 Hardware</p><p>Current Safety Limiter Setpoint: 457°C</p><p>Desired Safety Limiter Setpoint: 457°C</p><p>Number of Polls: 9</p><div>Cancel</div></div>	<p>From this point onward the NGC-CMA device will be sending the new set point at regular intervals to the DigiTrace NGC-20 hardware (Polling). The polling process will be repeated until the process is cancelled or until the Safety Limiter Set button inside the unit is pressed. Press and hold the button for 3 seconds.</p> <p>The Display of the DigiTrace NGC-20 will flash briefly and show actual and new safety limiter setpoint.</p> <p>The Safety Limiter Temperature Set button is the Black Push button on the left-hand side of the DigiTrace NGC-20 hardware as is shown in Figure 23 5 .</p>

Figure 23 4: writing a new Safety LimiterSetpoint




Figure 23 5: Location of limiter temperature set button and Limiter Reset button inside the DigiTrace NGC-20 control unit enclosure.

Safety limiter setpoint

Safety Limiter Setpoint

Press Safety Limiter
Set Button In
NGC-20 Hardware



Number of Polls: 5

Cancel

Figure 23 6: Limiter cut out temperature updated successfully.

After the new set point has been successfully updated a pop up message as shown in Figure 23 6 confirming the new set point has been successfully updated.

Note: that the new set point may differ 1 or 2 degrees from the selected values. This is caused by rounding up or rounding down the set point while it is been converted by the internal electronics.

23.2. Resetting Safety Temperature Limiter

Once the safety Temperature limiter has tripped it will need to be reset in order to restore normal operation. Resetting the Safety Temperature limiter will only be possible after safe operating conditions have returned. Look at Fig. 7.4 in order to find see where the RESET button is located inside the enclosure.

Reset protection Password

Enter 547 to continue

Min: 100 Max: 999

7	8	9	Clear
4	5	6	Cancel
1	2	3	Enter
0	.	-	+

Figure 23 7: Resetting – rearming the Safety temperature Limiter

Resetting the safety temperature limiter is a safety Function therefore the Reset operation is protected by a password in order to prevent the safety temperature limiter form being reset unintentionally.

The safety temperature limiter can be reset from the DigiTrace NGC-CMA. In order to do so, tap on **Reset Tripped Limiter**. This will open a new screen as is shown in Figure 23 7.

Use the numeric Key pad to enter the number shown in blue on the top of the screen and tap enter.

Successfully Reset Tripped Limiter

Safety Limiter Parameters

Firmware:
2.0

Safety Limiter Status:



Trip Safety Limiter

Back

Figure 23 8: Resetting – rearming the safety temperature limiter



If the number entered was correct than the safety temperature limiter will reset and a pop up screen will appear

The pop up screen confirms the safety temperature limiter has been successfully reset.

Tap OK when done

23.3. Trip Limiter

The trip safety limiter is a test function of the SIL 2 approved safety temperature limiter.

Limiter Parameters (Trip Limiter)	
 <p>Figure 23 9: Limiter cut out temperature updated successfully.</p>	<p>This is the test function of the SIL 2 approved safety temperature limiter. Hit this field in order to Test the safety temperature limiter at regular intervals at least once every year.</p>
	<p>When tripped a screen will pop up confirming that the safety temperature limiter has tripped successfully.</p> <p>In order to rearm the Safety temperature Limiter follow the procedure as explained in paragraph 23.2.</p> <p>Back will return to the NGC-20 Configuration Screen.</p>

24. MAINTENANCE DATA

The Maintenance data screens provide the possibility to look at Minimum and Maximum values of recorded data. The DigiTrace NGC-20 control unit measures many variables such as; voltage, current, temperature, ground fault etc. and for each of these the highest and lowest value ever measured is stored in the DigiTrace NGC-20 memory. The Maintenance screens of the NGC-CMA enable to visualise and to reset this data.

Note: Maintenance data is stored until it will be manually reset. After resetting the measuring process will start again and stores new Min / Max values until the next reset.

Tap on Maintenance to go to the Maintenance menu.







Figure 24 1: NGC-20 Configuration Screen

In total there are 4 screens showing NGC-20 control units maintenance data.

Reset Maintenance (1)	
 <p>Figure 24 2: Maintenance data screen 1</p>	<p>Records are kept of:</p> <p>Control Temperature,</p> <p>AC Voltage</p> <p>Tap on the blue field Reset in order to reset the actual values. This will bring up a screen as shown in Figure 24 3.</p>

Resetting values	
 <p>Figure 24 3: Reset Maintenance data</p>	<p>Confirm that you want to clear actual maintenance data.</p> <p>Tap No to Abort or Tap Yes to clear the actual values. A similar screen will be used for other variables as well.</p>

Reset Maintenance (2)	
 <p>Figure 24 4: Maintenance data screen 2</p>	<p>Highest Instantaneous Ground Fault</p> <p>Highest instantaneous Load Current</p>

Reset Maintenance (3)

Reset Maintenance

Relay Cycle Count

Reporting: 1566 cycles

Reset Relay Cycle Count

Heater Time

Reporting: 95 hrs

Reset Heater Time

1	2	3	4	
Back				

Figure 24 5: Maintenance data screen 3

Contactor Cycle count

Heater Time

Reset Maintenance (4)

Reset Maintenance

Safety Limiter

Min. Temp: 25 °c

Max. Temp: 180 °c

Reset Safety Limiter Max/Min

1	2	3	4	
Back				

Figure 24 6: Maintenance data screen 4

Safety Limiter Min / Max temperatures

Tap on **Back** when done.

25. DIGITRACE NGC-20 MONITORING SCREENS

Besides its function as a programming and configuration interface the DigiTrace NGC-CMA can also be used to monitor DigiTrace NGC-20 units while they are in operation. When used in monitoring mode all process variables measured by the NGC-20 control units can be visualised on the NGC-CMA. Tap on the monitoring field to continue. This will open the first of a total of 6 available monitoring screens. Use the Left / Right buttons on the bottom of the screen to cycle through the different screens.

The following parameters are permanently monitored:


Monitoring Screen 1	
 <p>NGC-20 Monitoring</p> <p>Control Temperature: Reporting: 24 °C</p> <p>Load Current: Reporting: 0.0 A</p> <p>Voltage: Reporting: 231 V</p> <p>Ground Fault Current: Instantaneous: 0 mA</p> <p>Safety Limiter Status: Latch Temporarily Dis.</p> <p>Safety Limiter Temperature: Reporting: 121 °C</p> <p>Back < ></p>	<p>Control Temperature: Shows the actual temperature used by the DigiTrace NGC-20 for control. Based on this temperature the output will be switched ON / OFF.</p> <p>Load Current: current uptake of the load(s) connected to the control output of the DigiTrace NGC-20 control Unit.</p> <p>Note: that the load connected to the daisy chain terminals will not be monitored.</p> <p>Voltage: actual power supply voltage</p> <p>Ground Fault Current: instantaneous ground fault current</p> <p>Limiter Status: shows actual limiter status.</p> <p>Limiter Temperature Reporting: this field shows the actual limiter temperature measured by the Limiter RTD.</p>

Figure 25 1: NGC-20 Monitoring Screen


Monitoring Screen 2	
 <p>NGC-20 Monitoring</p> <p>Source Temperatures:</p> <p>1: 24 °C</p> <p>2: Not Used</p> <p>3: Not Used</p> <p>4: Not Used</p> <p>Back < ></p>	<p>Source Temperatures:</p> <p>This field shows the Temperatures measured by all temperatures presently connected. Temperature sources 3 and 4 require the use of an optional NGC-UIT and MONI-RMM2 device.</p> <p>Tap on Back to return to the NGC-20 Configuration Screen.</p>

Figure 25 2: NGC-20 Monitoring Screen 2

26. DIGITRACE NGC-20 ALARM SCREENS

Tap on the View Alarms screen in order to investigate and eventually reset actual alarms. In the Active Alarms field all alarms are shown.


NGC-20 Alarms	
 <p>NGC-20 Alarms</p> <p>Active Alarms</p> <p>Control Temperature High</p> <p>Temperature Sensor 1 High</p> <p>Reset Selected Alarm</p> <p>Reset All Alarms</p> <p>Back</p>	<p>In order to reset an alarm select the alarm by tapping on that specific alarm in the Active alarms window and then hit Reset Selected Alarm. The Reset All Alarms button resets all actual alarms in a single operation.</p> <p>Note that Alarms can only be reset after the event causing the alarm has been resolved or the measured value has changed such that the actual reading is within the alarm boundaries.</p> <p>Tap on Back when done and to return to the NGC-20 Configuration Screen.</p>

Figure 26 1: NGC-20 Alarms Screen

Example: a low temperature alarm can only be reset when the temperature has increased to a value above the low temperature alarm set point.



Figure 26 2: NGC-20 Main screen

27. UPGRADING FIRMWARE OF THE DIGITRACE NGC-20 CONTROL UNIT

Remark: the Firmware / Settings menu items are identical with the “Standard Mode” menu items. Therefore most items will not be repeated. See for more details Chapter 16.

The Update Firmware function allows installing new revisions of DigiTrace NGC-20 firmware in the controller via the DigiTrace NGC-CMA and the wireless Bluetooth interface. This procedure can be performed on units while they are in operation. During the firmware upload process the DigiTrace NGC-20 unit will be out of service for about 2 minutes. For safety reasons the output of the controller will be off during the entire upgrade process.

Click on Firmware/Settings in the main screen. Select Update Firmware button to initiate the process. This will open the Firmware update screen.

Firmware Update	
<div><p><i>Firmware Update</i></p><p>Tag: NGC20-Demo 03</p><p>Current Firmware: 3.14.13</p><p>Selected Firmware:</p><div>Firmware File: <input type="text"/></div><div>Back Upload</div></div>	<p>Current Firmware shows the revision number of the Firmware currently installed.</p> <p>Firmware File: tap on the blue field showing the three dots in order to brows to the location where the new firmware file is installed. Firmware files are binary files and are having the extension “.bin”</p>

Figure 27 1: Installing new Firmware

Select Firmware File

Select Firmware File



Figure 27 2: Selection new Firmware

Tapping on this field will open a new screen. On this screen all available versions of DigiTrace-NGC-20 firmware currently present on the NGC-CMA firmware folder will be listed.

Note: the DigiTrace firmware files are binary files. New configuration files need to be placed in the folder **Application Data\DigiTrace\NGC CMA\NGC20 Firmware**. This folder will be automatically installed while installing the application.

Select the new file by tapping on it and hit **OK**.

Warning: don't try to upload files other than original files provided by Pentair Thermal Management. Any attempt to try to upload false or incomplete files may damage the DigiTrace NGC-20 Control unit

Firmware Update

Firmware Update




Figure 27 3: Updating Firmware

After the new file is selected hit **Upload** to start the upload process.

The existing Firmware version as well as the new Firmware are shown on the DigiTrace NGC-CMA screen

The installation procedure will remove the existing version and install new software in the DigiTrace NGC-20 control unit.

The installation progress can be followed on the **Progress** bar and on the installation progress timer.

Once the upload process is complete the DigiTrace NGC-20 control unit will briefly show the Firmware version number on the display and return to normal operation.

Firmware Update (Complete)




Figure 27 4: Successful update firmware

If the installation was successful a pop up window will appear confirming the firmware update was successful.

APPENDICES AND INDEXES

CONTROL MODE DEFINITIONS

On/Off

The NGC-20 monitors the control temperature and compares it to the setpoint. If the control temperature is above the setpoint by more than the Deadband value the relay output is turned off. If the control temperature falls below the setpoint temperature, the output is turned on. The control temperature is defined as the lowest RTD temperature input value.

Additional Entry Fields:

Deadband If the control temperature is above the Setpoint temperature plus Deadband, the relay output is turned off. If the control temperature is below the Setpoint temperature, the output is turned on.

Range: 1°C (2°F) to 50°C (90°C)

Default: 3°C (5°F)

PASC (Proportional Ambient Sensing Control)

PASC takes advantage of the fact that the heat loss from a pipe is proportional to the temperature difference between the pipe and the ambient air. This is true regardless of heater type, insulation type, or pipe size. Once the heat tracing and insulation on a pipe has been designed to balance heat input with heat loss and maintain a particular temperature, the main variable in controlling the pipe temperature becomes the ambient air temperature.

The NGC-20 has a control algorithm that uses the measured ambient temperature, desired maintain temperature, minimum ambient temperature assumption used during design, and size of the smallest pipe diameter to calculate how long the heater should be on or off to maintain a near-constant pipe temperature.

Additional Entry Fields:

PASC Min Ambient Temp The Min Ambient Temp is the “lowest ambient temperature” that was used when the heat-tracing system was designed. The entered value should agree with the value used by the design engineer to ensure that the heat tracing system was sized correctly

Range: -73°C (-99°F) to 51°C (125°F)

Default: -40°C (-40°F)

PASC Min Pipe Size Min Pipe Size is the diameter of the smallest heat-traced pipe in the group controlled by this circuit. Small diameter pipes heat up and cool down more rapidly than larger diameter pipes therefore, the PASC duty cycle is calculated over a shorter time base. Larger diameter pipes heat and cool less rapidly, the on/off periods for the heater system can be stretched over a longer period. If electromechanical contactors are being used to control the heater circuit, the longer the time base reduces the number of contactor on/off cycles and extends the contactor life.

List: 1.27cm (0.5in), 2.54cm (1in), 5.08cm (2in)

Default: 1.27cm (0.5in)

Power Adjust This allows the PASC control to be adjusted when the heating cable output is greater than the design assumption, or if the pipe insulation proves to be more efficient than assumed. Pipe temperature may run higher or lower than desired if the heating cable has a different output than required to offset the heat loss. The Power Adjust parameter enables a reduction or an increase in the heat-tracing effective power by entering a value less or greater than 100%

IMPORTANT: If improperly used, the Power Adjust parameter can cause the piping to get too cold or too hot. If unsure, leave at 100%. Do not change this value unless an engineer calculates the temperature impact on the system and determines that it is safe to do so. Be particularly cautious if the circuit has more than one diameter of pipe or type of heat tracing. Contact a Pentair Thermal Management representative for assistance with this factor.

Range: 10–200%

Default: 100%

BELGIË / BELGIQUE

Tel. +32 16 21 35 02
Fax +32 16 21 36 04
salesbelux@pentair.com

BULGARIA

Tel./fax +359 56 86 68 86
fax +359 56 86 68 86
salesee@pentair.com

ČESKÁ REPUBLIKA

Tel. +420 241 009 215
Fax +420 241 009 219
czechinfo@pentair.com

DANMARK

Tel. +45 70 11 04 00
Fax +45 70 11 04 01
salesdk@pentair.com

DEUTSCHLAND

Tel. 0800 1818205
Fax 0800 1818204
salesde@pentair.com

ESPAÑA

Tel. +34 902 125 307
Fax +34 91 640 29 90
ptm-sales-es@pentair.com

FRANCE

Tél. 0800 906045
Fax 0800 906003
salesfr@pentair.com

HRVATSKA

Tel. +385 1 605 01 88
Fax +385 1 605 01 88
salesee@pentair.com

ITALIA

Tel. +39 02 577 61 51
Fax +39 02 577 61 55 28
salesit@pentair.com

LIETUVA/LATVIJA/ESTI

Tel. +370 5 2136633
Fax +370 5 2330084
info.baltic@pentair.com

MAGYARORSZÁG

Tel. +36 1 253 7617
Fax +36 1 253 7618
saleshu@pentair.com

NEDERLAND

Tel. 0800 0224978
Fax 0800 0224993
salesnl@pentair.com

NORGE

Tel. +47 66 81 79 90
Fax +47 66 80 83 92
salesno@pentair.com

ÖSTERREICH

Tel. 0800 297410
Fax 0800 297409
info-ptm-at@pentair.com

POLSKA

Tel. +48 22 331 29 50
Fax +48 22 331 29 51
salespl@pentair.com

REPUBLIC OF KAZAKHSTAN

Tel. +7 495 926 18 85
Fax +7 495 926 18 86
saleskz@pentair.com

РОССИЯ

Тел. +7 495 926 18 85
Факс +7 495 926 18 86
salesru@pentair.com

SERBIA AND MONTENEGRO

Tel. +381 230 401 770
Fax +381 230 401 770
salesee@pentair.com

SCHWEIZ / SUISSE

Tel. 0800 551308
Fax 0800 551309
info-ptm-ch@pentair.com

SUOMI

Puh. 0800 11 67 99
Telekopio 0800 11 86 74
salesfi@pentair.com

SVERIGE

Tel. +46 31 335 58 00
Fax +46 31 335 58 99
salesse@pentair.com

TÜRKİYE

Tel. +90 530 977 64 67
Fax +32 16 21 36 04
ptm-sales-tr@pentair.com

UNITED KINGDOM

Tel. 0800 969013
Fax 0800 968624
salesthermaluk@pentair.com



WWW.PENTAIRTHERMAL.COM

All Pentair trademarks and logos are owned by Pentair or its global affiliates. Pentair reserves the right to change specifications without prior notice.

© 2013 Pentair.